

FOTILE

คู่มือการใช้งาน

วิธีการใช้งานเพื่อความปลอดภัยที่สำคัญ
อ่านอย่างละเอียดและเก็บไว้อ้างอิงในอนาคต

เตาไมโครเวฟ

HW25800K-01AG
HW25800K-03G/03BG
HW25800K-C2G



ขอบคุณสำหรับการเลือกซื้อสินค้าของเรา

โปรดอ่านคู่มือการใช้งานอย่างละเอียดก่อนการใช้งานและเก็บรักษาไว้อ่างอิงในอนาคต

สารบัญ

คำเตือนและวิธีการใช้งานเพื่อความปลอดภัย	1
วิธีการใช้งานเพื่อความปลอดภัยที่สำคัญ	1
ข้อควรระวังล่วงหน้า	1
เครื่องใช้ในบ้านที่สามารถปรับใช้	2
การหลีกเลี่ยงการเกิดไฟลุกไหม้และความร้อนลวก	4
รายการในบรรจุภัณฑ์	5
ข้อมูลจำเพาะและตำแหน่งต่างๆ ของเตาไมโครเวฟ	6
การติดตั้ง	7
ข้อควรระวังล่วงหน้า	7
ขั้นตอนการติดตั้ง	8
การใช้งาน	8
การนำทาง	8
การเริ่มใช้งาน	9
ไมโครเวฟและการย่าง	9
ฟังก์ชันละลายน้ำแข็ง	9
แผงควบคุม	10
การทำความสะอาดและการบำรุงรักษา	18
คำแนะนำในการปรุงอาหาร	19
การปรุงอาหารด้วยเตาไมโครเวฟ	19
วิธีการละลายอาหารแช่แข็ง	20
เหตุการณ์ปกติและการแก้ไขปัญหา	21
ข้อควรระวังล่วงหน้า	21
เหตุการณ์ปกติ	21
การแก้ไขปัญหาเบื้องต้น	21

คู่มือการใช้งานฉบับนี้ประกอบไปด้วยเนื้อหาที่เป็นปัจจุบันจนถึงขั้นตอนการพิมพ์เป็นรูปเล่ม เราพยายามอย่างมากในการพัฒนานวัตกรรมใหม่ทางเทคนิค เราขอสงวนสิทธิ์ในการพัฒนาหรือแก้ไขสินค้าและคู่มือการใช้งานโดยไม่แจ้งให้ทราบล่วงหน้า ภาพตัวอย่างบางภาพในคู่มือการใช้งานฉบับนี้ใช้สำหรับการอ้างอิงเท่านั้นและรูปลักษณะที่แท้จริงของสินค้าอาจจะแตกต่างจากภาพตัวอย่าง

คำเตือนและวิธีการใช้งานเพื่อความปลอดภัย

● วิธีการใช้งานเพื่อความปลอดภัยที่สำคัญ

- คำเตือน: ส่วนประกอบที่สามารถเข้าถึงได้อาจจะเกิดความร้อนในขณะที่ทำการย่าง ควรกันเด็กออกจากเตาไมโครเวฟ
- คำเตือน: ตรวจสอบจนมั่นใจว่าเตาไมโครเวฟปิดการใช้งานก่อนเปลี่ยนหลอดไฟเพื่อป้องกันการเกิดไฟฟ้าช็อต ถ้าหากสายไฟชำรุด ต้องได้รับการเปลี่ยนโดยผู้ผลิต ตัวแทนบริการหรือบุคคลที่มีคุณสมบัติเหมาะสมเพื่อป้องกันการเกิดอันตราย
- คำเตือน: ถ้าประตูหรือผนังของประตูเตาไมโครเวฟชำรุด ห้ามใช้เตาไมโครเวฟจนกว่าจะได้รับการซ่อมแซมโดยช่างผู้ชำนาญ
- คำเตือน: ตรงนี้จะก่อให้เกิดอันตรายสำหรับคนอื่น ๆ นอกเหนือจากบุคคลที่มีความชำนาญในการตรวจสอบหรือซ่อมแซมซึ่งเกี่ยวข้องกับการถอดตัวเครื่องที่ใช้ป้องกันการกระจายของรังสีไมโครเวฟและแรงดันไฟฟ้าสูง
- คำเตือน: ของเหลวหรืออาหารอื่นๆ ต้องไม่ถูกปรุงในขณะที่อยู่ภาชนะปิดสนิทเพื่อป้องกันการระเบิด
- คำเตือน: อนุญาตให้เด็กสามารถใช้เตาไมโครเวฟโดยไม่ต้องมีการแนะนำเมื่อผู้ปกครองสอนการใช้งานให้กับเด็กซึ่งเด็กสามารถใช้งานตามวิธีที่ปลอดภัยและเข้าใจถึงอันตรายในการใช้งานที่ไม่ถูกต้อง
- เตาไมโครเวฟไม่มีวัตถุประสงค์ในการใช้งานโดยบุคคล (รวมถึงเด็ก) ที่ด้อยการรับรู้ทางด้านร่างกายหรือด้อยทางด้านจิตใจหรือขาดประสบการณ์และความรู้ ยกเว้นว่าพวกเขาได้รับคำแนะนำหรือวิธีการใช้งานเตาไมโครเวฟโดยบุคคลที่มีหน้าที่รับผิดชอบสำหรับความปลอดภัยของพวกเขา
- เด็กควรได้รับการแนะนำเพื่อให้มั่นใจว่าพวกเขาไม่เล่นเตาไมโครเวฟ
- ห้ามทิ้งเตาไมโครเวฟโดยไม่มีกรงแยกขยะ ใช้การบริการจัดเก็บขยะแบบพิเศษ
- ติดต่อตัวแทนของรัฐสำหรับข้อมูลเพิ่มเติมเกี่ยวกับระบบการจัดเก็บขยะเครื่องใช้ไฟฟ้า
- ถ้าหากเครื่องใช้ไฟฟ้าถูกทิ้งในกองขยะหรือทิ้งลงน้ำ อันตรายจากสารที่รั่วไหลลงในแหล่งน้ำใต้พื้นดินและไหลรวมเข้าสู่ห่วงโซ่อาหาร เป็นการทำลายสุขภาพและการใช้ชีวิตที่ดี
- เมื่อเปลี่ยนเตาไมโครเวฟเครื่องใหม่แทนที่เครื่องเก่า ผู้ค้าปลีกมีหน้าที่รับผิดชอบในการนำเตาไมโครเวฟเครื่องเก่ากลับคืนเพื่อนำมากำจัดโดยไม่มีค่าใช้จ่าย



● ข้อควรระวังไว้ล่วงหน้า

1. โปรดอ่านคู่มือการใช้งานฉบับนี้อย่างละเอียดก่อนเริ่มต้นการใช้งาน
2. เตาไมโครเวฟมีวัตถุประสงค์ในการใช้ปรุงอาหาร ละลายอาหารแช่แข็งและย่างอาหารภายในบ้านพักอาศัยเท่านั้น การใช้งานนอกเหนือจากที่กล่าวมาจะไม่ได้รับการรองรับโดยผู้ผลิตและอาจจะก่อให้เกิดอันตราย ผู้ผลิตจะไม่รับผิดชอบสำหรับความเสียหายที่มีสาเหตุมาจากการใช้เตาไมโครเวฟไม่ถูกต้องหรือไม่เหมาะสม
3. เตาไมโครเวฟไม่มีวัตถุประสงค์ในการใช้งานโดยเด็กหรือบุคคลที่ด้อยความสามารถยกเว้นว่าพวกเขาได้รับการแนะนำหรือสอนการใช้งานอย่างเหมาะสม
4. ตรวจสอบจนมั่นใจว่าแรงดันไฟฟ้าและความถี่ไฟฟ้าที่ใช้ตรงตามค่าที่แสดงอยู่ในคู่มือการใช้งานเพื่อป้องกันไม่ให้เตาไมโครเวฟเสียหายและตรวจสอบจนมั่นใจว่าได้รับการต่อสายดินอย่างถูกต้อง
5. ตรวจสอบว่าปลั๊กของเตาไมโครเวฟเสียบเข้ากับเต้าเสียบที่มีการต่อสายดินเพื่อป้องกันการเกิดไฟฟ้าช็อต
6. วางเตาไมโครเวฟตามแนวอนซึ่งมีการระบายอากาศเป็นอย่างดีและไม่มีสิ่งกีดขวาง ซึ่งจะต้องอยู่ห่างจากบริเวณที่มีอุณหภูมิสูงหรือมีไอน้ำ
7. วางเตาไมโครเวฟให้ห่างจากทีวี วิทยุและเสารับสัญญาณเพื่อป้องกันการเกิดคลื่นแทรก แนะนำควรห่างอย่างน้อย 5 เมตร

8. การติดตั้งและการซ่อมแซมจะต้องได้รับการปฏิบัติโดยบุคคลที่มีคุณสมบัติเหมาะสมตามข้อกำหนดเพื่อความปลอดภัยของประเทศหรือในท้องถิ่น การซ่อมแซมหรือการทำงานอื่นๆ โดยบุคคลที่ไม่เหมาะสมอาจจะก่อให้เกิดอันตราย ผู้ผลิตจะไม่รับผิดชอบสำหรับการซ่อมแซมหรือการทำงานอื่นๆ โดยบุคคลที่ไม่เหมาะสม

9. ห้ามแกะตัวเครื่อง

การดัดแปลงการเชื่อมต่อกระแสไฟหรือส่วนประกอบและส่วนของกลไกเป็นสิ่งที่เป็นการอันตรายอย่างมากและอาจจะทำให้เครื่องทำงานผิดปกติหรือเกิดไฟฟ้าช็อต

10. อย่าวางวัตถุบ่งบริเวณช่องระบายลมของเตาไมโครเวฟเพื่อทำให้มั่นใจว่าการระบายอากาศทำได้ดี

11. ห้ามเปิดใช้เตาไมโครเวฟในขณะที่ไม่มีอาหารอยู่ในเครื่อง ซึ่งอาจจะทำให้เตาไมโครเวฟเสียหาย หลังจากการใช้งาน วางแก้วใส่น้ำวางบนถาดกระจกเพื่อป้องกันไม่ให้เตาไมโครเวฟเสียหาย

12. ก่อนการเสิร์ฟอาหาร

จดจำไว้ว่าควรมีระยะเวลาพักและควรตรวจสอบอุณหภูมิของอาหารเป็นประจำหลังจากที่นำออกจากเตาไมโครเวฟ อุณหภูมิของภาชนะไม่ได้บ่งบอกถึงอุณหภูมิของอาหารหรือของเหลวภายในภาชนะ

13. ห้ามนำตัวจับอุณหภูมิที่มีปรอทหรือของเหลวเข้าไปในเตาไมโครเวฟเพื่อวัดความร้อนหรือวัดค่าอื่นๆ เนื่องจากอาจจะทำให้เกิดประกายไฟหรือทำให้เตาไมโครเวฟเสียหาย

หยุดการปรุงอาหารชั่วคราวก่อนตรวจสอบอุณหภูมิของอาหาร


14. ห้ามใช้ไมโครเวฟ ถ้า

- ประตูของเตาไมโครเวฟปิดเบี้ยว
 - บานพับของประตูเตาไมโครเวฟหลวม
 - เกิดรูหรือรอยร้าวที่มองเห็นได้ตรงตัวเครื่อง ประตูเตาไมโครเวฟหรือผนังภายใน
- การใช้เตาไมโครเวฟในขณะที่เกิดความเสียหายเหล่านี้จะทำให้รังสีไมโครเวฟรั่วไหลซึ่งเป็นอันตรายสำหรับผู้ใช้งาน






15. ห้ามปฏิบัติดังต่อไปนี้เพื่อป้องกันไม่ให้ถาดแก้วเสียหาย

- ห้ามวางถาดด้วยน้ำจนกว่าถาดแก้วจะเย็นตัวลง
- ห้ามวางภาชนะหรืออาหารที่มีความร้อนสูงลงบนถาดแก้วที่เย็น
- ห้ามวางอาหารหรือภาชนะที่เย็นจัดบนถาดแก้วที่ร้อนอยู่
- ห้ามวางอาหารหรือภาชนะต่างๆ ที่มีน้ำหนักมากกว่า 5 กิโลกรัม
- ห้ามใช้เตาไมโครเวฟเพื่อจัดเก็บอาหาร
- ใช้อุปกรณ์เสริมที่ได้รับอนุญาตจากบริษัท FOTILE เท่านั้น

● ภาชนะภายในบ้านที่สามารถปรับใช้

- ★ ใช้เครื่องใช้ที่เหมาะสมสำหรับการใช้งานร่วมกับเตาไมโครเวฟเท่านั้น
- ★ วิธีการตรวจสอบว่าภาชนะภายในบ้านสามารถใช้ร่วมกับเตาไมโครเวฟหรือไม่
 - คำแนะนำ  นำภาชนะภายในบ้านใส่ในเตาไมโครเวฟพร้อมแก้วใส่น้ำขนาด 300 มิลลิลิตร และเลือกโหมดไมโครเวฟ สำหรับการปรุงอาหารนาน 1 นาที
 - ภาชนะภายในบ้านจะสามารถใช้งานร่วมกับไมโครเวฟได้ถ้าหากภาชนะไม่ร้อนในขณะที่น้ำร้อน ในทางกลับกัน ภาชนะที่ไม่สามารถใช้งานได้ถ้าหากภาชนะเกิดความร้อนซึ่งมีการดูดซึมจำนวนคลื่นไมโครเวฟ
 - วิธีการนี้ห้ามปรับใช้กับภาชนะที่เป็นพลาสติก
- ★ ภาชนะที่ไม่เหมาะในการใช้งานกับเตาไมโครเวฟไม่เพียงจะทำให้รสชาติของอาหารออกมาไม่ดีแต่ยังทำลายเตาไมโครเวฟหรือภาชนะ ดูรายละเอียดในตารางเพื่ออ้างอิง

ประเภทของภาชนะ	เตาไมโครเวฟ	อย่าง	การอย่างผสม
 เครื่องแก้วทนความร้อน	สามารถใช้ ⚠ เมื่อคุณทำแยมโปรดใช้เครื่องแก้วทนความร้อนเป็นพิเศษซึ่งสามารถทำให้เย็นหรือร้อนได้อย่างรวดเร็ว	ไม่สามารถใช้	ไม่สามารถใช้
 เครื่องแก้วไม่ทนความร้อน	ไม่สามารถใช้ ⚠ รวมถึงแก้วตัดและแก้วนิรภัย	ไม่สามารถใช้	ไม่สามารถใช้
 ภาชนะพลาสติกทนความร้อน	สามารถใช้ ⚠ โปรดใช้ภาชนะที่มีเครื่องหมาย "ใช้สำหรับเตาไมโครเวฟ" ⚠ ให้ความใส่ใจในฝาปิดพลาสติกซึ่งอาจจะไม่ทนความร้อน ⚠ หลีกเลี่ยงการใช้ฝาปิดที่ปิดสนิท ⚠ ห้ามปรุงอาหารที่มีน้ำมันหรือน้ำตาลเป็นจำนวนมากซึ่งอาจจะทำให้เกิดความร้อนสูง	ไม่สามารถใช้ ⚠ สามารถใช้ภาชนะพลาสติกสำหรับย่าง	ไม่สามารถใช้
 ภาชนะพลาสติกไม่ทนความร้อน	ไม่สามารถใช้ ⚠ ห้ามใช้ภาชนะพลาสติกที่ไม่ได้ผลิตมาเพื่อใช้ร่วมกับเตาไมโครเวฟ อย่างเช่น โพลีเทน เมลามีน ไฮดรอกซีเบนซีน และยางคาบารไมด์ เป็นต้น ⚠ ถาดโฟมสามารถใช้สำหรับการละลายอาหารสดแช่แข็งเท่านั้น	ไม่สามารถใช้	ไม่สามารถใช้T
 ภาชนะเคลือบ	ไม่สามารถใช้ ⚠ สีที่ระบายบนจานอาจจะหลุดหรือแตกออก	ไม่สามารถใช้	ไม่สามารถใช้
 ภาชนะเซรามิค	สามารถใช้ ⚠ ภาชนะที่มีการระบายสีหรือตกแต่งด้วยสีทอง/เงินไม่สามารถใช้ได้เนื่องจากอาจจะทำให้เกิดประกายไฟ	สามารถใช้ ⚠ ห้ามใช้ภาชนะเซรามิคที่มีการระบายสีภายในซึ่งสีอาจจะลอก	สามารถใช้

ประเภทของภาชนะ	เตาไมโครเวฟ	อย่าง	การอย่างผสม
 ภาชนะโลหะ (อย่างเช่น อลูมิเนียม)	ไม่สามารถใช้ได้ ⚠ ห้ามใช้ตะแกรงโลหะหรือโลหะ ซึ่งอาจจะทำให้เกิดประกายไฟ ⚠ ไม่ควรใช้ภาชนะโลหะทาสีที่ใช้สำหรับเตาไมโครเวฟ	สามารถใช้ ⚠ ห้ามใช้ภาชนะที่มีที่จับเป็นยาง ไม่สามารถใช้	ไม่สามารถใช้
 ภาชนะที่ทำจากไม ไมไฟเบอร์หรือกระดาษ	ไม่สามารถใช้ ⚠ ภาชนะประเภทนี้อาจจะติดไฟได้	ไม่สามารถใช้ ⚠ ภาชนะกระดาษทน ความร้อนสามารถใช้ได้	ไม่สามารถใช้
 ถาดตะแกรงสำหรับย่าง	ไม่สามารถใช้	สามารถใช้	สามารถใช้
 แผ่นฟิล์มบางสำหรับใช้ กับเตาไมโครเวฟ	สามารถใช้ ⚠ ภาชนะที่มีน้ำมันจำนวนมากไม่ สามารถใช้ได้	ไม่สามารถใช้ ⚠ ฟิล์มอาจจะละลาย ด้วยอุณหภูมิสูง	ไม่สามารถใช้
 ฟอยอลูมิเนียม	ไม่สามารถใช้ ⚠ สามารถใช้ถ้าหากฟอยผลิตเพื่อ ลดการสะท้อนคลื่นไมโครเวฟและ เพื่อใช้การละลายอาหารแช่แข็ง	สามารถใช้ ⚠ ห่ออาหารใน ฟอยอลูมิเนียมสำหรับย่าง	ไม่สามารถใช้

● การหลีกเลี่ยงการเกิดประกายไฟ ระเบิดหรือความร้อนลวก

- เพื่อป้องกันไม่ให้ภายในเตาไมโครเวฟเกิดประกายไฟ โปรดปฏิบัติตามดังต่อไปนี้
 - ห้ามห่อหุ้มอาหารก่อนทำการปรุงอาหาร
 - ก่อนทำการปรุงอาหารที่ห่อด้วยกระดาษหรือถุงพลาสติก โปรดแกะห่อออกก่อน
 - เมื่อปรุงอาหารในภาชนะพลาสติกหรือกระดาษ คอยดูภายในเตาไมโครเวฟตลอดเวลาเนื่องจากอาจจะเกิดประกายไฟ
 - เมื่อปรุงอาหารด้วยภาชนะที่ใช้ครั้งเดียว โปรดตรวจสอบอาหารภายในเตาไมโครเวฟเสมอ
 - ห้ามอุ่นแอลกอฮอล์ น้ำมันหรืออาหารทอด เนื่องจากไม่สามารถควบคุมอุณหภูมิของน้ำมันได้
 - เมื่อปรุงอาหารจำนวนน้อย ให้ความใส่ใจเพื่อป้องกันอันตรายจากความร้อนสูง
 - หลังปรุงอาหารแต่ละครั้ง ใช้ผ้าชุบน้ำบิดหมาดหรือผ้าแห้งทำความสะอาดคราบอาหารหรือคราบน้ำมันที่ผนังภายในเตาไมโครเวฟเพื่อป้องกันการเกิดควันดำหรือไฟลุกไหม้

- ถ้าภาชนะสำหรับปรุงอาหารเกิดติดไฟ ปิดเตาไมโครเวฟทันที ใช้การดับไฟที่เหมาะสม เช่น การปิดประตูเตาไมโครเวฟให้สนิทคอยดูและระวังอาหารที่มีน้ำตาลเป็นจำนวนมากในขณะปรุงหรืออุ่นอาหาร ถ้าหากปรุงหรืออุ่นเป็นเวลานาน น้ำตาลอาจจะตกผนังหรือเกิดประกายไฟ
 - เพื่อหลีกเลี่ยงการเป็นเชื้อเพลิงหรือประกายไฟ ห้ามเปิดประตูเตาไมโครเวฟถ้าหากเกิดควันภายในเตาไมโครเวฟหยุดการใช้เตาไมโครเวฟ ปิดการใช้งานและถอดปลั๊ก ห้ามเปิดประตูเตาไมโครเวฟจนกว่าควันจะหมด
 - อาหารในชวดนามหรือเหยือกป้อนอาหารเด็กขนาดเล็กควรทำการคนหรือเขย่าและตรวจดูอุณหภูมิก่อนบริโภค เพื่อป้องกันความร้อนลวก
- เพื่อหลีกเลี่ยงการระเบิด ควรปฏิบัติตามดังต่อไปนี้
 - ห้ามปรุงอาหารในภาชนะปิดสนิท อย่างเช่น ชวดนมที่ปิดฝาหรือหัวจุกดูด
 - ในขณะปรุงของเหลว โปรดใช้ภาชนะขอบหนาและภาชนะมีพื้นที่มากพอสำหรับของเหลวเดือด
 - การอุ่นเครื่องดื่มด้วยเตาไมโครเวฟอาจจะทำให้เกิดการเดือดล้นซ้ำ ดังนั้น โปรดระวังในขณะนำภาชนะออกจากเตาไมโครเวฟ
 - ก่อนปรุงอาหารที่มีลักษณะกลมหรือเป็นแท่งอย่างเช่น มันฝรั่ง เกาลัดหรือไส้กรอก โปรดใช้มีดหรือข้อมจิ้มที่อาหารเพื่อให้มีการระเหยของน้ำเพื่อป้องกันการระเบิด
 - ห้ามนำไข่ต้มหรือของเหลวออกจากเตาไมโครเวฟทันทีเพื่อหลีกเลี่ยงการแตกออกในภายหลัง เพื่อป้องกันการระเบิด ห้ามปรุงอาหารประเภทไข่ที่สดหรือที่ปรุงแล้วซึ่งยังมีเปลือกไข้อยู่
 - ห้ามนำไข่วกหรือบัวลอยออกจากเตาไมโครเวฟทันทีเพื่อป้องกันการระเบิด รอสักพักก่อนเปิดประตูเตาไมโครเวฟ
 - เพื่อหลีกเลี่ยงการถูกความร้อนลวกจากการเดือดทันที โปรดปฏิบัติตามดังต่อไปนี้
 - นำอาหารที่ปรุงเสร็จออกจากเตาไมโครเวฟโดยสวมถุงมือกันความร้อนเพื่อป้องกันการถูกไอร้อนลวก
 - เมื่อสร้างความร้อนภาชนะหลอดแก้วหรืออาหารที่ปรุงเสร็จใหม่ ห้ามสัมผัสบริเวณด้านบนของภายในเตาไมโครเวฟ ดังนั้น การปรุงอาหารในหม้อ ย่าง ใช้ถุงมือเพื่อกลับอาหารเนื่องจากภายในเตาไมโครเวฟมีความร้อนสูง
 - เพื่อหลีกเลี่ยงการถูกความร้อนลวก อาหารในชวดนามหรือชวดสำหรับเด็กอ่อนควรได้รับการคนหรือเขย่าและตรวจดูอุณหภูมิก่อนบริโภคทุกครั้ง






รายการในบรรจุภัณฑ์

- นำผลิตภัณฑ์และอุปกรณ์ทั้งหมดออกจากบรรจุภัณฑ์และตรวจดูอย่างละเอียดว่าเตาไม่มีความเสียหาย
 - เตาถูกกระแทกหรือกดทับด้วยวัตถุน้ำหนักมากหรือไม่?
 - ประตูเตาไมโครเวฟเรียบและสวิตช์ถูกเปิดอยู่หรือไม่?
 - บริเวณประตูเตาไมโครเวฟที่เป็นโลหะมีการบุหรือเสียรูปทรงหรือไม่?
 - สายไฟชำรุดหรือหลวมหรือไม่?
 ถ้าคุณพบข้อผิดพลาดตามที่กล่าวมาข้างต้น โปรดติดต่อฝ่ายบริการของ FOTILE
- รายการในบรรจุภัณฑ์

ชื่อ	จำนวน
เตาไมโครเวฟ	1
คู่มือการใช้งาน	1
สกรูไม้หัวกากบาทพ่นสีดำ M4 x 24 ตัว	4
ชั้นตะแกรง	1
ถาดแก้ว	1
แกนหมุนถาด	1

ข้อมูลจำเพาะและตำแหน่งต่างๆ ในไมโครเวฟ

รุ่น	HW25800K-01AG	HW25800K-03G/03BG	HW25800K-C2G
แรงดันไฟฟ้า	220-240V 50Hz	220-240V 50Hz	220-240V 50Hz
ไฟฟ้านำเข้า	1150 – 1350 วัตต์ (ไมโครเวฟ) 750 – 850 วัตต์ (ย่าง)		
กำลังไฟนำออก (ไมโครเวฟ)	800 วัตต์		
ความถี่ (ไมโครเวฟ)	2450MHz		
ขนาดภายนอก (ยาว x กว้าง x สูง)	595 x 385 x 368 มิลลิเมตร		595x385x416 มิลลิเมตร
ความจุของเตา	25 ลิตร		
อุปกรณ์สำหรับการสร้างความร้อนอย่างเดียว	ถาดแก้วชนิดพิเศษ		
น้ำหนักสุทธิ	20 กิโลกรัม	22 กิโลกรัม	20 กิโลกรัม



ภาพตัวอย่าง


- ระบบล็อกภายในเพื่อความปลอดภัย:
ทำให้มั่นใจว่าเตาไมโครเวฟจะไม่ทำงานเมื่อประตูเตาไมโครเวฟปิดสนิทเท่านั้น
- แกนหมุนถาดแก้ว: ทำให้ถาดแก้วหมุนรอบ
- ส่วนประกอบของวงแหวนหมุน: รองรับถาดแก้วและหมุนไปตามเส้นทาง
- ช่องภายในเตาไมโครเวฟ
- แผงควบคุม: โปรดดูคำอธิบายสำหรับแผงควบคุม
- หน้าต่างดูภายในเตาไมโครเวฟ: เพื่อดูอาหารภายในโดยผ่านช่องกระจกครอบโลหะ
- ถาดแก้ว: ภาชนะที่ใส่อาหารจะต้องวางบนถาดแก้วซึ่งจะหมุนเพื่อให้อาหารเกิดความร้อนอย่างทั่วถึง
- ตะแกรง: ใช้สำหรับหม้อทอดหรือหม้อทอดลมเท่านั้น
- ไมก้า: เพื่อป้องกันไอระเหยหรือไขมันเข้าไปในท่อ ไมก้าจะต้องไม่ถูกถอดออก ซึ่งอาจจะส่งผลกับการทำงานของเตาไมโครเวฟ

การติดตั้ง


การเตรียมก่อนการติดตั้ง




เตาไมโครเวฟจะต้องได้รับการติดตั้งในตู้วางหนึ่งใบในสามแบบตามภาพที่แสดงอยู่ด้านล่าง (ตู้วางกับพื้น ตู้ติดผนังและตู้สูง) ซึ่งมีช่องระบายอากาศที่ดี ถ้าหากผู้ใช้ไม่ได้ติดตั้งเตาไมโครเวฟในตู้ทั้งสามแบบนี้ FOTILE จะไม่รับผิดชอบสำหรับอุบัติเหตุต่างๆ ที่เกิดขึ้น



● ขั้นตอนการติดตั้ง




แผนภาพการติดตั้งตู้บิวท์อินแบบบางส่วน



แผนภาพการติดตั้งตู้บิวท์อินแบบสมบูรณ์

1. ดันเตาไมโครเวฟเข้าไปในตู้วาง
2. ขอบเตาไมโครเวฟและตู้วางต้องมีระยะห่างอย่างน้อย 8 มิลลิเมตร
3. ยึดเตาไมโครเวฟกับตู้วางด้วยสกรูแบบ ST4x25 ทั้งหมด 4 ตัว



หน่วย : นิ้ว (มิลลิเมตร)

การใช้งาน

★ การใช้งานสำหรับเตาไมโครเวฟรุ่น HW25800K-03G/03BG/01AG

● การนำทาง

1. เสียบปลั๊กของเตาไมโครเวฟ
2. นำอาหารวางบนถาดแก้วและปิดประตูเตาไมโครเวฟ ระวังห้ามเปิดใช้เตาไมโครเวฟถ้าหากไม่มีอาหารอยู่ภายในเครื่อง เพื่อป้องกันไม่ให้เตาไมโครเวฟเสียหาย
3. เลือกโหมดการปรุงอาหาร
 - a. นำตะแกรงย่างออกถ้าหากเลือกฟังก์ชัน "ไมโครเวฟ"
 - b. ตรวจสอบว่าอาหารและหลอดสร้างความร้อนจะต้องห่างประมาณ 5 มิลลิเมตรเป็นอย่างต่ำ ถ้าหากเลือกใช้ฟังก์ชันผสมอาหารจะต้องได้รับการกลับด้านในระหว่างการปรุง

4. ตั้งเวลาปรุงอาหาร

5. เตาไมโครเวฟเริ่มทำงานตามโปรแกรมที่เลือก โปรแกรมจะหยุดชั่วคราวถ้าประตูเตาไมโครเวฟถูกเปิด ในทางกลับกัน เตาไมโครเวฟจะกลับมาทำงานหลังจากกดปุ่ม "เริ่ม"
6. เราแนะนำอย่างยิ่งว่าควรสวมถุงมือกันความร้อนในระหว่างการนำอาหารออกจากเตาไมโครเวฟ ห้ามสัมผัสโดนผนังภายในเตาไมโครเวฟ
7. ในโหมดผสมหรือโหมดย่าง ห้ามสัมผัสด้านบน ประตูเตาไมโครเวฟและทั้งสองด้านภายในเตาไมโครเวฟเนื่องจากบริเวณเหล่านี้จะมีความร้อนสูง จะมีเสียงเตือนดัง 3 ครั้งก่อนที่เตาไมโครเวฟหยุดทำงาน และไฟแสดงสถานะจะดับ

● การใช้งานเริ่มแรก

เมื่อใช้เตาไมโครเวฟเป็นครั้งแรก คุณอาจจะได้กลิ่นเหม็นและแม้แต่เห็นควันสีขาวจากเตาไมโครเวฟ ตรงนี้เป็นเรื่องปกติ และหลังจากการใช้งานผ่านไปหลายครั้ง ตรงนี้จะไม่เกิดขึ้นอีก

ตรวจสอบดูจนมั่นใจว่าประตูและหน้าต่างภายในห้องเปิดอยู่เพื่อการระบายอากาศที่ดี

คุณจะต้องปฏิบัติตามขั้นตอนเหล่านี้เพื่อป้องกันเหตุการณ์นี้เกิดขึ้นอยู่เสมอ:

1. ก่อนเริ่มต้นใช้โหมด ย่าง ครั้งแรกเพื่อทำให้อาหารแห้งหลายครั้ง



การทำให้อาหารแห้งจะต้องใช้โหมด ย่าง เสมอ ห้ามใช้โหมด ไมโครเวฟหรือโหมดผสม

2. ก่อนเริ่มต้นใช้งานครั้งแรก เลือกโหมด ไมโครเวฟ

และนำแก้วใส่น้ำวางไว้บนถาดแก้วเพื่อทำให้น้ำเดือดด้วยความร้อนสูงหลายๆ ครั้ง

● โหมดไมโครเวฟและย่าง

1. คลื่นไมโครเวฟสามารถทะลุผ่านได้

คลื่นไมโครเวฟสามารถทะลุผ่านอาหารและทำให้อาหารสุกในเวลาอันสั้นโดยไม่ทำให้น้ำของอาหารสูญเสีย ดังนั้นคลื่นไมโครเวฟไม่สามารถทำให้พื้นผิวของอาหารเป็นสีน้ำตาลและอาหารกรอบได้

2. ความร้อนของฟังก์ชัน ย่าง มาจากการแผ่ความร้อนจากหลอดความร้อน ซึ่งจะทำพื้นผิวของอาหารเป็นสีน้ำตาล แต่ถ้าหากอาหารบางอย่างมาก ตรงนี้อาจจะทำให้ภายในอาหารไม่สุกในขณะที่พื้นผิวของอาหารไหม้เกรียม ดังนั้นโหมดผสมระหว่างไมโครเวฟและการย่างสามารถใช้ประโยชน์จากทั้งสองโหมดเพื่อทำให้อาหารออกมาดูดีและรสชาติดี



ห้ามใช้โหมดไมโครเวฟเมื่อเตาไมโครเวฟไม่มีอาหารอยู่ภายใน

และห้ามใช้ภาชนะโลหะซึ่งอาจจะทำให้เกิดประกายไฟหรือความเสี่ยงที่ก่อให้เกิดอันตรายต่างๆ

● ฟังก์ชันการละลายอาหารแช่แข็ง

ตรงนี้เป็นลักษณะเฉพาะตัวอย่างหนึ่งของเตาไมโครเวฟในการละลายอาหารแช่แข็ง

การละลายน้ำแข็งด้วยไมโครเวฟจะทำให้รวดเร็วกว่าเตาไฟฟ้าและปลอดภัยมากกว่าการละลายน้ำแข็งด้วยอุณหภูมิห้อง

เนื่องจากไม่ทำให้แบคทีเรียกระจายตัวในไมโครเวฟ หมุนลูกบิดไปยังฟังก์ชันละลายอาหารแช่แข็ง

และหมุนลูกบิดเวลาเพื่อตั้งระยะเวลาการละลายอาหารแช่แข็งตามน้ำหนักของอาหาร

เนื่องจากคลื่นไมโครเวฟไม่สามารถทะลุผ่านวัตถุที่มีความหนาเกิน 4 ซม. ในแต่ละด้าน






คุณจะต้องกลับอาหารเป็นระยะถ้าหากอาหารมีความหนา

เราแนะนำว่าให้นำอาหารที่ละลายแล้วออกเพื่อให้อาหารแช่แข็งที่เหลือสามารถละลายได้ง่ายมากขึ้น มิเช่นนั้น

อาจจะทำพื้นผิวของอาหารละลายในขณะที่ภายในอาหารยังแข็งอยู่

1. ตรึงน้ำจำเป็นต้องกลับอาหารในระหว่างการละลายน้ำแข็งเพื่อให้มั่นใจว่าอาหารได้รับการละลายอย่างทั่วถึง
2. การละลายน้ำแข็งเสร็จสิ้นเมื่ออาหารสามารถตัดด้วยมีด
3. การละลายอาหารแช่แข็งจะใช้เวลานานกว่าการปรุงอาหาร
4. อาหารที่ได้รับการละลายจะต้องนำมาปรุงและบริโภคทันที ห้ามนำกลับไปแช่ในตู้เย็นอีกครั้ง

● แผงควบคุม

1. เปิดใช้เตาไมโครเวฟ หน้าจอ LED กระทบ 3 ครั้งเพื่อแสดงฟังก์ชันทั้งหมด และ “:” จะกระทบเลือกเวลาหรือฟังก์ชันการปรุงอาหาร
2. การตั้งเวลา (24 ชั่วโมง)
เมื่อหน้าจอแสดง “:” กดปุ่ม “ตั้งนาฬิกา” (preset clock) และใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)” เพื่อยืนยันการตั้งชั่วโมง กดปุ่ม “ตั้งนาฬิกา” (preset clock) และใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)” เพื่อยืนยันการตั้งนาที สุดท้าย กดปุ่ม “ตั้งนาฬิกา” (preset clock) ตามขั้นตอนข้างต้น การตั้งนาฬิกาจะเสร็จสมบูรณ์ และเวลาปัจจุบันจะแสดงขึ้นมา วิธีการตั้งเวลาใหม่หรือเปลี่ยนเวลาโปรดทำซ้ำตามขั้นตอนข้างต้น
3. การตั้งค่าระดับความร้อน
กดปุ่ม “ไมโครเวฟ” ในแต่ละครั้ง หน้าจอจะแสดง “100P”, “80P”, “60P”, “40P”, “20P” สลับไป ใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)” เพื่อยืนยันการตั้งเวลา และกดปุ่ม “เริ่มต้น” เพื่อเริ่มต้นการปรุงอาหารตามระดับความร้อนที่ตั้งไว้
100P : คลื่นไมโครเวฟ 100% (ความร้อนสูง) ตมน้ำ ปรุงผลไม้ ผักสดและผลไม้แห้ง
80P : คลื่นไมโครเวฟ 80% (ความร้อนค่อนข้างสูง) ปรุงปลา อาหารทะเล เนื้อ สัตว์ปีก ไช้ เค้ก
60P : คลื่นไมโครเวฟ 60% (ความร้อนกลาง) อบเค้ก ตมอาหาร ละลายเนยและซอสค็อกแลต
40P : คลื่นไมโครเวฟ 40% (ความร้อนค่อนข้างต่ำ) ปรุงชิ้นเนื้อ เคี้ยวซูบ ทำให้เนยนุ่มลง
20P : คลื่นไมโครเวฟ 20% (ความร้อนต่ำ) อุ่นอาหาร ทำให้ไอศกรีมอ่อนตัวลง
4. เริ่มใช้งานแบบด่วน
กดปุ่ม “ด่วน” (Express) แต่ละครั้ง หน้าจอ LED แสดงระยะเวลา “0:30”, “1:00” และ “1:30” ตามลำดับ
0:30: เวลาหลักคือ 30 วินาที
1:00: เวลาหลักคือ 1 นาที
1:30: เวลาหลักคือ 1 นาที 30 วินาที
กดปุ่ม “เริ่มต้น” เพื่อเริ่มต้นปรุงอาหารด้วยความร้อนสูงตามเวลาที่เลือก
5. การย่างคลื่นต่ำ
กดปุ่ม “ย่าง” (Grill) และใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)” เพื่อยืนยันการตั้งเวลา
กดปุ่ม “เริ่มต้น” เพื่อปรุงอาหารตามเวลาที่เลือก ฟังก์ชัน “การย่างคลื่นต่ำ” ใช้เพื่อการปรุงเนื้อชิ้น เช่น สเต็กเนื้อ สเต็กหมบาร์บีคิวไส้กรอกและปีกไก่ ยังสามารถใช้สำหรับอบแซนวิชและทำให้อาหารกรอบ
6. ไมโครเวฟ+ย่าง (แบบผสม)
กดปุ่ม “ย่างผสม” (Grill Combi) ในแต่ละครั้งและหน้าจอ LED แสดง “Grill combi1” “Grill combi2” และ “Grill combi3” ตามลำดับ

Grill Combi1: ใช้โหมดไมโครเวฟ 30% และโหมดย่าง 70% สำหรับระยะเวลาปรุงอาหารทั้งหมด เหมาะสำหรับการย่างแนะนำสำหรับปรุงอาหารตะวันตก อย่างเช่น สเต็กเนื้อ

Grill Combi2: ใช้โหมดไมโครเวฟ 55% และโหมดย่าง 45% สำหรับระยะเวลาปรุงอาหารทั้งหมด
ค่อนข้างปรุงอาหารได้รวดเร็วมากกว่า แนะนำสำหรับการอบสัตว์ปีกทั้งตัว อย่างเช่น ไก่ เป็ดหรือห่าน

Grill Combi3: ใช้โหมดไมโครเวฟ 70% และโหมดย่าง 30% ปรุงอาหารได้รวดเร็วที่สุด
แนะนำสำหรับการอบสัตว์ปีกทั้งตัว อย่างเช่น ไก่ เป็ด และห่าน

เมื่อเลือกใช้ฟังก์ชันผสม ใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)” เพื่อยืนยันการตั้งเวลาและกดปุ่ม “เริ่มต้น” เพื่อเริ่มปรุงอาหารตามเวลาที่กำหนด



ในโหมดผสม ตัวสร้างความร้อนทั้งหมดรวมถึงชั้นวางตะแกรงและภาชนะจะเกิดความร้อนสูงมาก ระวังในขณะที่นำอาหารออกจากเตาไมโครเวฟ
คุณควรสวมถุงมือกันความร้อนแบบหนาเพื่อใช้กับไมโครเวฟโดยเฉพาะเพื่อป้องกันการเกิดความร้อนลวก
ไม่จำเป็นต้องอุ่นเครื่องสำหรับโหมด “ย่าง”

7. การละลายอาหารแช่แข็งโดยอัตโนมัติ

กดปุ่ม “ละลายน้ำแข็งอัตโนมัติ” (Auto Defrost) และหน้าจอ LED แสดง “Defrost Meat” (ละลายเนื้อแช่แข็ง) “Defrost Poultry” (ละลายสัตว์ปีกแช่แข็ง) และ “Defrost Seafood” (ละลายอาหารทะเลแช่แข็ง) ตามลำดับ

Defrost Meat (ละลายเนื้อแช่แข็ง): ใช้สำหรับละลายเนื้อแช่แข็งซึ่งมีน้ำหนักระหว่าง 0.1 ถึง 2.0 กิโลกรัม

Defrost Poultry (ละลายสัตว์ปีกแช่แข็ง): ใช้สำหรับละลายสัตว์ปีกแช่แข็ง น้ำหนักอยู่ระหว่าง 0.2 ถึง 3 กิโลกรัม (สำหรับ HW25800K-01AG) 0.1 ถึง 2.0 กิโลกรัม (สำหรับ HW25800K-03G/03BG)

Defrost Seafood (ละลายอาหารทะเลแช่แข็ง): ใช้สำหรับละลายอาหารทะเลแช่แข็งน้ำหนักระหว่าง 0.1 ถึง 0.9 กิโลกรัม

เมื่อเลือกฟังก์ชันละลายอาหารแช่แข็ง ใช้ลูกบิด/ปุ่ม “ตั้งเวลา (Timer)/ Weight (น้ำหนัก)/ Auto (อัตโนมัติ)”

เพื่อยืนยันการกำหนดน้ำหนัก กดปุ่ม “เริ่มต้น” เมื่อโปรแกรมตรวจสอบว่าอาหารจำเป็นต้องมีการกลับด้านเสียงเตือนจะดังสองวินาทีเพื่อเตือน

8. หยุดชั่วคราว/ยกเลิก

กดปุ่ม “Pause/Cancel” (หยุดชั่วคราว/ยกเลิก) การตั้งค่าความร้อนเวลาหรือระยะเวลาการละลายน้ำแข็งจะถูกยกเลิก
ในขณะที่เตาไมโครเวฟกำลังทำงาน กดปุ่ม “Pause/Cancel” หนึ่งครั้งหรือเปิดประตูเตาไมโครเวฟ เตาคจะหยุดทำงาน
กดปุ่มนี้สองครั้ง โปรแกรมจะถูกยกเลิก

9. ปรับเมนูอัตโนมัติโดยการหมุนตัวตั้งรหัสไปทางซ้าย

A.1 ข้าว: สำหรับการหุงข้าวที่มีน้ำหนักระหว่าง 0.15 ถึง 0.6 กิโลกรัม (สำหรับ HW25800K-01AG) 0.1 ถึง 0.5 กิโลกรัม (สำหรับ HW25800K-03G/03BG)

A.2 ผักสด: สำหรับการปรุงผักสดที่มีน้ำหนักระหว่าง 0.1 ถึง 0.5 กิโลกรัม (สำหรับ HW25800K-01AG) 0.1 ถึง 0.6 กิโลกรัม (สำหรับ HW25800K-03G/03BG)

A.3 ข้าวโพดคั่ว: สำหรับการทำข้าวโพดคั่วที่มีน้ำหนักระหว่าง 0.07 ถึง 0.13 กิโลกรัม (สำหรับ HW25800K-01AG) 0.1 กิโลกรัม (สำหรับ HW25800K-03G/03BG)

A.4 มันฝรั่ง: สำหรับการปรุงมันฝรั่ง 1, 2 หรือ 3 หัว (แต่ละหัวมีน้ำหนักประมาณ 0.3 กิโลกรัม) (สำหรับ HW25800K-01G) หรือน้ำหนักระหว่าง 0.15 ถึง 0.6 กิโลกรัม (สำหรับ HW25800K-03G/03BG)

A.5 พิซซ่า: สำหรับการอบพิซซ่าโดยมีน้ำหนักโดยประมาณอยู่ระหว่าง 300 ถึง 500 กรัม (สำหรับ HW25800K-01AG) 150 ถึง 300 กรัม (สำหรับ HW25800K-03G/03BG)

- A.6 เครื่องดื่ม: สำหรับอุณหภูมิเครื่องดื่ม 1 ถึง 3 ถ้วย (แต่ละถ้วยมีน้ำหนักระหว่าง 230 มิลลิลิตร) (สำหรับ HW25800K-01AG) หรือเครื่องดื่มขนาด 250 กรัม, 500 กรัม หรือ 700 กรัม (สำหรับ HW25800K-03G/03BG)
- A.7 ปลา: สำหรับการปรุงอาหารประเภทปลาที่มีน้ำหนักระหว่าง 0.2 ถึง 0.6 กิโลกรัม (สำหรับ HW25800K-01AG) 0.1 ถึง 0.5 กิโลกรัม (สำหรับ HW25800K-03G/03BG) (ฟังก์ชันนี้จะหยุดชั่วคราวในครั้งแรกของระยะเวลาการปรุง เพื่อเตือนให้ผู้ใช้งานกลับด้านของปลา)
- A.8 ไก่: สำหรับการย่างไก่ที่มีน้ำหนักระหว่าง 0.8 ถึง 1.4 กิโลกรัม (สำหรับ HW25800K-01AG) 0.2 ถึง 1.2 กิโลกรัมสำหรับ HW25800K-03G/03BG) (ฟังก์ชันนี้จะหยุดชั่วคราวในครั้งแรกของระยะเวลาการปรุง มีการเตือนให้ผู้ใช้งานกับด้านของไก่)



- จากโปรแกรมข้างต้นได้รับการออกแบบมาเพื่อปรุงอาหารที่มีอุณหภูมิอยู่ระหว่าง 20 – 25 องศาเซลเซียส การปรุงอาหารที่เสร็จสิ้นจะมีอุณหภูมิที่แน่นอน โปรดปรับระยะเวลาด้วยตัวคุณเอง
- เราแนะนำให้ควรใช้ฟิล์มรัดเพื่อคลุมอาหารเมื่อปรุงมันฝรั่งหรือปลา เพื่อป้องกันการระเหยของน้ำในอาหาร
- รสชาติจะได้รับการกำหนดตามรูปทรง, น้ำหนักและอุณหภูมิของอาหาร เมื่อใช้ฟังก์ชัน "Auto Menu" (เมนูอัตโนมัติ) โปรดทำตามคำแนะนำข้างต้นและทำการปรับตามต้องการถ้าหากอาหารสุกไม่ทั่วถึง
- Auto Menu (เมนูอัตโนมัติ)
อาหารที่ปรุงเสร็จด้วยฟังก์ชัน "Auto Menu" ได้รับการกำหนดโดยความชอบส่วนตัวขนาด ปริมาณและการวางอาหารและแรงดันไฟฟ้าที่ใช้ ถ้าหากอาหารสุกไม่ทั่วถึง โปรดปรับระยะเวลาการปรุงอาหารตามสภาพของอาหารในการปรุงแต่ละครั้ง

10. โปรแกรมการปรุงอาหารแบบผสม

แบบผสม: ในแต่ละครั้ง (หรือแต่ละส่วน) จะใช้เวลาสูงสุด 30 นาที (HW25800K-01AG) 60 นาที (HW25800K-03B/03BG) ผู้ใช้งานสามารถปรุงอาหารได้ทั้งหมด 4 ส่วน ยกตัวอย่างเช่น ถ้าคุณต้องการตั้งเวลาสูงสุด 10 นาทีสำหรับโหมดไมโครเวฟและเพิ่มอีก 10 นาทีสำหรับโหมดย่าง คุณจะต้องทำตามขั้นตอนดังต่อไปนี้: กดปุ่ม "ไมโครเวฟ" หน้าจอ LED แสดง 100P และหมุนลูกบิด "Timer/Weight/Auto Menu" เพื่อตั้งเวลาอยู่ที่ "10:00" กดปุ่ม "ย่าง" และหมุนลูกบิด "Timer/Weight/Auto Menu" เมื่อหน้าจอ LED แสดง "10:00" กดปุ่ม "เริ่มต้น" และเตาไมโครเวฟจะเริ่มต้นปรุงอาหารตามโปรแกรมที่กำหนด ตรงนี้จะเริ่มต้นในส่วนแรกของโปรแกรมจนกระทั่งเวลานับถอยหลังถึง "0" หลังจากนั้นส่วนที่สองของโปรแกรมจะเริ่มต้นทำงานจนเสร็จ



โปรแกรมปรุงอาหารแบบผสมไม่สามารถตั้งในโหมด "Auto Menu"

11. การตั้งเวลาปรุงอาหาร



เมื่อโปรแกรมและระยะเวลาการปรุงอาหารปกติได้รับการกำหนด หน้าจอ LED แสดงเวลา ยกตัวอย่าง "8:28" กดปุ่ม "Preset Clock" (ตั้งนาฬิกา) ค้างไว้ 3 วินาที ตรงนี้จะเริ่มต้นนับเวลาถอยหลังในการปรุง เมื่อฟังก์ชันละลายอาหารแช่แข็งถูกเลือก หมุนลูกบิด "Timer/Weight/Auto Menu" เพื่อกำหนดชั่วโมงและกดปุ่ม "Preset Clock" และเมื่อฟังก์ชันละลายอาหารแช่แข็งถูกเลือก หมุนลูกบิด "Timer/Weight/Auto Menu" เพื่อตั้งนาฬิกาสุดท้าย กดปุ่ม "Preset Clock" หรือรอประมาณ 5 วินาทีเพื่อเริ่มต้นฟังก์ชันนี้ หน้าจอ LED จะแสดงเวลาปัจจุบัน ถ้าต้องการตรวจสอบดูเวลาที่ตั้งไว้ กดปุ่ม "Clock Setting" (ตั้งค่านาฬิกา) และหน้าจอ LED จะแสดงเวลาที่ตั้งไว้ เมื่อปล่อยนิ้วจากปุ่ม เวลาจะเปลี่ยนเป็นเวลาปัจจุบัน เมื่อฟังก์ชัน "Delay Time" (ตั้งเวลาปรุงอาหาร) เริ่มทำงาน

- กดปุ่ม "เริ่มต้น" ถ้าคุณต้องการเริ่มต้นการปรุงอาหารทันที
- กดปุ่ม "Pause/Cancel" ถ้าคุณต้องการยกเลิกฟังก์ชันนี้

12. เสียงเตือน

- เสียงเตือนที่ตั้งจะเตือนสำหรับการทำงานที่ใช้งานได้ และเสียงเตือนเบาจะดังเมื่อไม่สามารถใช้งาน
- เมื่อแต่ละโปรแกรมสิ้นสุดลง เสียงเตือนจะดัง 3 ครั้ง และหน้าจอ LED จะแสดงคำว่า "END" ถ้าหากไม่กดปุ่ม "Pause/Cancel" หรือประตูเตาไมโครเวฟไม่เปิดออก เสียงเตือนจะเตือนทุกๆ 3 นาที เมื่อประตูเตาไมโครเวฟเปิดออก หน้าจอ LED จะแสดง ":" หรือเวลาปัจจุบัน
- ในขณะที่เตาไมโครเวฟกำลังทำงานอยู่ กดปุ่ม "ไมโครเวฟ" และความร้อนในการปรุงอาหารปัจจุบันจะแสดงบนหน้าจอ LED ปล่อยนิ้วออกจากปุ่ม หน้าจอ LED จะแสดงเวลาที่เหลือของการปรุงอาหาร การทำงานของเตาไมโครเวฟในปัจจุบันจะได้รับผลกระทบ

13. ฟังก์ชันล็อกป้องกันเด็ก

เมื่อหน้าจอ LED แสดง ":" หรือเวลาปัจจุบัน กดปุ่ม "Pause/Cancel" ค้างไว้ 3 วินาที ฟังก์ชันล็อกป้องกันเด็กจะเริ่มต้นทำงานเมื่อได้ยินเสียงเตือนและหน้าจอ LED จะแสดง "  " เตาไมโครเวฟจะไม่สามารถใช้งานได้ เพื่อปลดล็อกเตาไมโครเวฟ กดปุ่ม "Pause/Cancel" ค้างไว้ 3 วินาที เสียงเตือนจะดังขึ้นและ "  " จะหายไปจากหน้าจอ LED



- ในขั้นตอนการตั้งค่าฟังก์ชัน ถ้าหากไม่มีการป้อนโปรแกรมภายใน 2 นาที หน้าจอจะแสดง ":" หรือเวลาปัจจุบัน
- ปุ่ม "เริ่มต้น" จะเปิดทำงานในสองสภาพการทำงานดังต่อไปนี้
 - เมื่อประตูเตาไมโครเวฟปิดใน 2 นาที
 - ปุ่ม "Pause/Cancel" กดภายใน 2 นาที มิเช่นนั้นเตาไมโครเวฟจะล็อก

14. ฟังก์ชันตั้งเวลาใช้พัลลัม

หลังจากเตาไมโครเวฟหยุดทำงาน พัลลัมจะยังคงทำงานต่อไปอีก 2 นาที หมายเหตุ: วิธีนี้จะเป็นการลดอุณหภูมิที่เพิ่มขึ้นของชิ้นส่วนไฟฟ้าภายในเตา ซึ่งช่วยเพิ่มอายุการทำงานของเตาไมโครเวฟ นอกจากนี้อุณหภูมิภายในตู้วางมีความปลอดภัยมากขึ้น

15. การควบคุมประตูเตาไมโครเวฟ:

เมื่อประตูเตาไมโครเวฟเปิดออก ไฟจะดับ ถ้าหากเตาไมโครเวฟกำลังทำงานอยู่ ถ้าหากการปรุงอาหารหยุดทำงาน นั้นหมายความว่าปุ่มถูกกดหนึ่งครั้ง หลังจากประตูเตาไมโครเวฟเปิดออก กดปุ่ม "OK" เพื่อเริ่มต้นใหม่



- หลังจากการปรุงอาหาร หน้าจอจะแสดงคำว่า "END" และมีเสียงเตือนดังทุก 3 นาที กดปุ่มเพื่อย้อนกลับไปยังโหมดแสดงตนบายด์
- ปุ่ม " ^ " หรือ " v " ในระหว่างการตั้งเวลา กดปุ่มเหล่านี้ซ้ำๆ หรือกดค้างเอาไว้

★ การใช้งานเตาไมโครเวฟรุ่น HW2500K-C2G



● การเปิดเครื่อง

เมื่อเปิดเครื่องเตาไมโครเวฟ ไฟบนหน้าจอทั้งหมดจะติดสว่างและหลังจากนั้นจะมีเสียงเตือนดังหนึ่งครั้ง และหน้าจอจะดับไป

สัมผัสที่ปุ่ม พาวเวอร์ และหน้าจอจะแสดง “⏰” เวลาปัจจุบันคือ 0:00

นาฬิกาจะเริ่มนับแสดงเวลาและจะเข้าสู่โหมดแสดงนบายด์

ในโหมดต่างๆ เมื่อกดปุ่ม พาวเวอร์หนึ่งครั้ง ไมโครเวฟจะปิดการทำงาน

ในโหมดปิดการทำงาน เมื่อสัมผัสที่ปุ่มใดปุ่มหนึ่งยกเว้นปุ่มพาวเวอร์ เตาจะไม่ทำงาน และเมื่อสัมผัสอีกครั้งเตาจะเข้าสู่โหมดแสดงนบายด์

หมายเหตุ: ในโหมดแสดงนบายด์ หน้าจอจะแสดงเฉพาะเวลาปัจจุบันและไอคอน “⏰”

1. การตั้งค่าการปรุงอาหารของเตาไมโครเวฟ

- การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์เมื่อกดที่ปุ่ม “F” หน้าจอจะแสดง “🔥” (กระป๋อง) P100 MW (กระป๋อง) “----” และปุ่มฟังก์ชันพื้นฐานอื่นๆ จะติดสว่าง
- การตั้งระดับความร้อน: ระดับความร้อนของเตาไมโครเวฟสามารถควบคุมได้โดยใช้ปุ่ม “^” หรือ “v” ระดับความร้อนจะวนรอบระหว่าง P100 ⇌ P80 ⇌ P60 ⇌ P40 ⇌ P20” เมื่อเลือกกำลังการปรุงที่ต้องการ กดปุ่ม “OK” เพื่อยืนยัน และเวลาจะเริ่มนับจาก “0:10”
- การตั้งเวลา: ระยะเวลาการทำงานของเตาไมโครเวฟสามารถตั้งได้โดยใช้ปุ่ม “^” หรือ “v” และกดปุ่ม “OK” เพื่อยืนยัน หลังจากนั้นเตาไมโครเวฟจะเริ่มทำงาน

2. การตั้งค่าการย่าง

- การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์เมื่อกดที่ปุ่ม F หน้าจอจะแสดง “🔥🔥” (กระป๋อง) Grill Grill (กระป๋อง) และปุ่มฟังก์ชันพื้นฐานอื่นๆ จะติดสว่าง
- การตั้งเวลา: ระยะเวลาการทำงานของเตาไมโครเวฟสามารถตั้งได้โดยใช้ปุ่ม “^” หรือ “v” และกดปุ่ม “OK” เพื่อยืนยันและการย่างจะเริ่มทำงาน

3. การตั้งค่าการทำงานร่วมกันระหว่างการอบและการย่าง:

- การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์เมื่อสัมผัสที่ปุ่ม F หน้าจอจะแสดง “🔥🔥” (กระป๋อง) “🔥🔥” Co-1 Baking and grilling combination และปุ่มฟังก์ชันพื้นฐานอื่นๆ ติดสว่าง

B. การตั้งเวลา: ระยะเวลาการทำงานของเตาไมโครเวฟสามารถตั้งค่าได้โดยใช้ปุ่ม “^” หรือ “v” และกดปุ่ม OK เพื่อยืนยัน การรวมกันระหว่างการอบและการย่างจะเริ่มทำงาน

การรวมกันระหว่างการอบและการย่าง 1: เหมาะสำหรับปรุงอาหารสดไก่หรือเป็ดทั้งตัว อาหารในลักษณะเดียวกันนี้

การรวมกันระหว่างการอบและการย่าง 2: เหมาะสำหรับปรุงอาหารตะวันตกเสต็กปลา และอื่นๆ

4. การตั้งค่าในการละลายอาหารแช่แข็ง:

A. การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์เมื่อสัมผัสที่ปุ่ม F หน้าจอจะแสดง “❄️” (กะพริบ) “0.10” “kg” “Defrost” และปุ่มฟังก์ชันพื้นฐานต่างๆ จะติดสว่าง

B. การตั้งค่าน้ำหนัก: น้ำหนักของอาหารแช่แข็งที่ต้องการละลายสามารถกำหนดได้โดยใช้ปุ่ม “^” หรือ “v” “0.10 ⇌ 0.20 ⇌ 0.30 1.70 ⇌ 1.80” และกดปุ่ม “^” หรือ “v” เพื่อยืนยัน หลังจากนั้นการละลายอาหารแช่แข็งจะเริ่มทำงาน

5. การตั้งค่านาฬิกา (ระบบ 24 ชั่วโมง)

A. การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์ กดปุ่ม F หน้าจอจะแสดง “🕒” (กะพริบ) “Hour” (กะพริบ) “Clock” (กะพริบ) และปุ่มฟังก์ชันพื้นฐานอื่นๆ จะติดสว่าง

B. การตั้งหน่วยชั่วโมง: กดปุ่ม “^” หรือ “v” เพื่อปรับค่า “ชั่วโมง” ตามต้องการ และกดปุ่ม “OK” เพื่อยืนยัน หน้าจอแสดง “Minute” (กะพริบ) “Clock” (กะพริบ) และปุ่มฟังก์ชันต่างๆ ติดสว่าง

C. การตั้งค่านาที: กดปุ่ม “^” หรือ “v” เพื่อปรับค่า “ชั่วโมง” ตามเวลาที่ต้องการ และกดปุ่ม “OK” เพื่อยืนยัน การตั้งค่าเสร็จสิ้น เตาไมโครเวฟจะย้อนกลับไปยังโหมดแสดงนบายด์

ตัวอย่างเช่น

เวลาปัจจุบันคือ “0:00” และเวลาที่ต้องการตั้งคือ “12:30”

สัมผัสปุ่ม “F” ทดครั้ง และหน้าจอจะแสดง “Clock” (กะพริบ) กดปุ่ม “^” หรือ “v” เพื่อปรับค่า “Hour” (ชั่วโมง)

เป็น “12” และกดปุ่ม “OK” เพื่อยืนยัน “12:00” (“:00” กะพริบ) และส่วนอื่นไม่มีการเปลี่ยนแปลง หลังจากนั้นกดปุ่ม “^” หรือ “v” เพื่อปรับค่า “Minute” (นาที) เป็น “30” และกดปุ่ม OK เพื่อยืนยัน หน้าจอจะแสดง “12:30” และ “🕒”

การตั้งนาฬิกาเสร็จสิ้น

6. การตั้งค่าเมนูปรุงอาหาร:

A. การเลือกฟังก์ชัน: ในโหมดแสดงนบายด์ สัมผัสที่ปุ่ม “🍲” เพื่อเลือกเมนู

B. การตั้งค่าน้ำหนัก: กดปุ่ม “^” หรือ “v” เพื่อตั้งค่าน้ำหนักต่างๆ สำหรับเมนู กดปุ่ม “OK”

(1) ข้าว: เหมาะสำหรับปรุงข้าวที่มีน้ำหนักระหว่าง 0.15 ถึง 0.60 กิโลกรัม

(2) ผัก: เหมาะสำหรับปรุงอาหารประเภทผักที่มีน้ำหนักระหว่าง 0.10 ถึง 0.50 กิโลกรัม

(3) เนื้อ: เหมาะสำหรับปรุงเนื้อสัตว์ที่มีน้ำหนักระหว่าง 0.20 ถึง 0.60 กิโลกรัม (กลับด้านอาหารเมื่อมีเสียงเตือน)

(4) พิซซ่า: เหมาะสำหรับปรุงพิซซ่าที่มีน้ำหนักระหว่าง 0.30 ถึง 0.50 กิโลกรัม

(5) เครื่องดื่ม: เหมาะสำหรับปรุงเครื่องดื่มหรือของเหลวที่มีความจุ 230 มิลลิลิตรสำหรับ 1-3 ถ้วย

(6) พัพ: เหมาะสำหรับพัพข้าวโพดที่มีน้ำหนัก 0.07 ถึง 0.13 กิโลกรัม

(7) ปลา: เหมาะสำหรับปรุงปลาที่มีน้ำหนักระหว่าง 0.20 ถึง 0.60 กิโลกรัม

ยกตัวอย่างเช่น การหุงข้าวน้ำหนัก 0.30 กิโลกรัม

ในโหมดแสดงนบายด์ กดปุ่ม “🍲” และหน้าจอจะแสดง “0.15kg” “kg” “rice” (กะพริบ) และปุ่มฟังก์ชันพื้นฐานต่างๆ จะติดสว่าง

กดปุ่ม “^” หรือ “v” เพื่อตั้งค่าน้ำหนักของข้าว และน้ำหนักตั้งอยู่ที่ 0.30 กิโลกรัม หลังจากยืนยันน้ำหนัก กดปุ่ม OK เพื่อยืนยัน การหุงข้าวจะเริ่มขึ้น (การตั้งค่าเมนูอื่นๆ จะเหมือนกับวิธีการหุงข้าวดังที่กล่าวมา)



1. จากโปรแกรมข้างต้นได้รับการออกแบบมาเพื่อปรุงอาหารที่มีอุณหภูมิอยู่ระหว่าง 20 – 25 องศาเซลเซียส การปรุงอาหารที่เสร็จสิ้นจะมีอุณหภูมิที่แน่นอน โปรดปรับระยะเวลาด้วยตัวคุณเอง

2. เราแนะนำว่าควรใช้ภาชนะสำหรับไมโครเวฟแบบพิเศษเมื่อทำการหุงข้าวเพื่อป้องกันไม่ให้เกิดการระเหยของน้ำหรือข้าว

3. เราแนะนำว่าควรใช้ฟิล์มรัดเพื่อคลุมอาหารเมื่อปรุงมันฝรั่งหรือปลา เพื่อป้องกันการระเหยของน้ำในอาหาร

4. รสชาติจะได้รับการกำหนดตามรูปทรง น้ำหนักและอุณหภูมิของอาหาร เมื่อใช้ฟังก์ชัน “Auto Menu” (เมนูอัตโนมัติ) โปรดทำตามคำแนะนำข้างต้นและทำการปรับตามต้องการถ้าหากอาหารสุกไม่ทั่วถึง

5. Auto Menu (เมนูอัตโนมัติ)

อาหารที่ปรุงเสร็จด้วยฟังก์ชัน “Auto Menu” ได้รับการกำหนดโดยความชอบส่วนตัวขนาด

ปริมาณและการวางอาหารและแรงดันไฟฟ้าที่ใช้ ถ้าหากอาหารสุกไม่ทั่วถึง

ปรับระยะเวลาการปรุงอาหารตามสภาพของอาหารในการปรุงแต่ละครั้ง

7. การตั้งค่าฟังก์ชันล็อกป้องกันเด็ก

ล็อก: ในโหมดแสดงนบายด์ สัมผัสที่ปุ่ม “C/L” ค้างไว้ 3 วินาที หน้าจอจะแสดง: เวลาปัจจุบัน “🕒” “🔒”

และหลังจากนั้นการล็อกป้องกันเด็กจะเสร็จสมบูรณ์ ในขณะเดียวกันนี้ปุ่มทั้งหมดจะไม่สามารถกดได้ยกเว้นปุ่ม “C/L” และปุ่มพาวเวอร์

ปลดล็อก: ในโหมดแสดงนบายด์ สัมผัสที่ปุ่ม “C/L” ค้างไว้ 3 วินาที หน้าจอจะแสดง เวลาปัจจุบัน “🕒”

และหลังจากนั้นการปลดล็อกป้องกันเด็กจะเสร็จสมบูรณ์

8. การตั้งค่าฟังก์ชันการเลือกหลายตัวเลือก:

เมื่อการเลือกหลายตัวเลือกได้รับการกำหนด ไมโครเวฟ, ย่าง, การรวมการอบและการย่าง 1 และ

การรวมการอบและการย่าง 2 จะสามารถเลือกโดยการเลือกหลายตัวเลือก ตรงนี้ห้ามตั้งค่า P100

ไมโครเวฟ หรือการย่าง หรือการรวมการอบและการย่าง 1 และการรวมการอบและการย่าง 2 สามารถเลือกในครั้งเดียว การเลือกหลายตัวเลือกสามารถเลือกตัวเลือกได้สูงสุดสามตัวเลือกในแต่ละครั้ง

ยกตัวอย่างเช่น: เมื่อต้องการต้มซูบซึ่งใช้ระดับความร้อนแตกต่างกัน

(1) เลือกตัวเลือกแรก: ตั้งระดับความร้อนที่ P100 นาน 6 นาทีซึ่งเป็นการตั้งค่าของไมโครเวฟ (ไม่ต้องกดปุ่ม “OK”)

(2) เลือกตัวเลือกที่สอง: ตั้งระดับความร้อนที่ P40 นาน 5 นาทีซึ่งเป็นการตั้งค่าของไมโครเวฟ (ไม่ต้องกดปุ่ม “OK”)

(3) เลือกตัวเลือกที่สาม: ตั้งระดับความร้อนที่ P20 นาน 4 นาทีซึ่งเป็นการตั้งค่าของไมโครเวฟ หลังจากนั้นกดปุ่ม “OK” เพื่อเริ่มต้นทำการต้มซูบ

หมายเหตุ: ฟังก์ชันนี้ถูกใช้สำหรับการปรุงอาหารที่ต้องการปรับระดับความร้อนอย่างเช่นการต้มซูบ ต้มไก่ เป็นต้น

9. การตั้งค่าการใช้งานด่วน

ในโหมดแสดงนบายด์ กดปุ่ม “^” หรือ “v” เวลาจะเพิ่มขึ้นทีละ 30 วินาทีเมื่อกดหนึ่งครั้ง เวลาสูงสุดที่ตั้งได้คือ 10 นาที หลังจากตั้งเวลาแล้ว กดปุ่ม “OK” เพื่อยืนยัน และเตาไมโครเวฟจะเริ่มต้นทำงาน ระดับความร้อนที่ใช้คือ P100

10. การยกเลิกหรือการหยุดชั่วคราว

ในขณะที่ทำการตั้งค่าฟังก์ชันให้กดปุ่ม “C/L” หนึ่งครั้ง

การตั้งค่าฟังก์ชันปัจจุบันจะถูกยกเลิกและกลับไปยังโหมดแสดงนบายด์

หลังจากเริ่มต้นทำงาน กดปุ่ม “C/L” หนึ่งครั้ง การทำงานจะหยุดชั่วคราว กดปุ่ม “OK” เพื่อเริ่มปรุงอาหารต่อ หรือกดปุ่ม “C/L” อีกครั้งเพื่อย้อนกลับไปยังโหมดแสดงนบายด์โดยตรง

11. ฟังก์ชันย้อนกลับอัตโนมัติ

ในระหว่างการตั้งค่าฟังก์ชัน ตรงนี้จะย้อนกลับไปยังโหมดแสดงนาฬิกาเมื่อไม่มีการกดปุ่มใดๆ

12. ฟังก์ชันการร้องขอ

ในระหว่างที่เตาไมโครเวฟทำงานอยู่ กดปุ่ม "F" หนึ่งครั้ง หน้าจอจะแสดง "⌚" จะแสดงเวลาปัจจุบัน ตรงนี้จะย้อนกลับไปยังการทำงานที่เลือกไว้

13. ฟังก์ชันตั้งเวลาเปิดพัดลม

หลังจากเตาไมโครเวฟหยุดทำงาน พัดลมจะเปิดทำงานต่อไปอีก 2 นาที

หมายเหตุ: วิธีนี้จะช่วยลดอุณหภูมิที่เพิ่มขึ้นภายในตัวสร้างความร้อน เพื่อช่วยเพิ่มอายุการใช้งานของเตาไมโครเวฟ นอกจากนี้ยังช่วยลดอุณหภูมิของตู้วางให้ปลอดภัย

14. การควบคุมประตูเตาไมโครเวฟ

เมื่อประตูเตาไมโครเวฟเปิดออกไฟจะดับ ถ้าหากเตาไมโครเวฟกำลังทำงานอยู่ ถ้าหากการปรุงอาหารหยุดทำงาน ตรงนี้หมายความว่าปุ่ม "C/L" ถูกกดหนึ่งครั้ง หลังจากนั้นเปิดประตูเตาไมโครเวฟ กดปุ่ม "OK" เพื่อเริ่มต้นใหม่



1. หลังจากการปรุงอาหาร หน้าจอจะแสดงคำว่า "END" และมีเสียงเตือนดังทุก 3 นาที กดปุ่มเพื่อย้อนกลับไปยังโหมดแสดงนาฬิกา
2. ปุ่ม "$^$" หรือ "$^$" ในระหว่างการตั้งเวลา กดปุ่มเหล่านี้ซ้ำๆ หรือกดค้างเอาไว้

การทำความสะอาดและการบำรุงรักษา

ถอดปลั๊กเตาอบไมโครเวฟก่อนทำความสะอาด

★ เตาไมโครเวฟควรได้รับการทำความสะอาดเป็นประจำ

ห้ามใช้เครื่องทำความสะอาดแบบพ่นไอน้ำทำความสะอาดเตาไมโครเวฟ

ไอน้ำที่พ่นออกมาอาจจะเข้าถึงชิ้นส่วนอิเล็กทรอนิกส์และทำให้เกิดไฟฟ้าลัดวงจร

ถ้าหากอาหารหรือของเหลวที่มีส่วนผสมของเกลือกระเด็นภายในเตาไมโครเวฟ

เช็ดทำความสะอาดทันทีเพื่อป้องกันไม่ให้เกิดการกัดกร่อนของพื้นผิว

★ การละลายที่รักษาให้เตาไมโครเวฟสะอาดอยู่เสมอจะทำให้พื้นผิวเกิดการกัดกร่อนซึ่งอาจจะส่งผลกับอายุการใช้งานและเป็นผลให้เกิดเหตุการณ์ที่เป็นอันตราย

★ พื้นผิวของเตาไมโครเวฟ

- ทำความสะอาดพื้นผิวด้วยผ้าชุบน้ำผสมน้ำยาที่มีฤทธิ์เป็นกลาง ห้ามใช้น้ำยาที่มีฤทธิ์กัดกร่อน

★ แผงควบคุม

- ระวังนิ้วมือทำความสะอาดแผงควบคุม ใช้ผ้าชุบน้ำบิดหมาดเช็ดทำความสะอาด (ถ้าหากแผงควบคุมเปียก ใช้ผ้าแห้งเช็ดอีกครั้ง) ห้ามขัดถูแผงควบคุมหรือทำความสะอาดด้วยน้ำยาที่มีฤทธิ์กัดกร่อน

★ ตะแกรงย่าง

- หลังใช้งาน ทำความสะอาดตะแกรงด้วยน้ำยาทำความสะอาดที่มีฤทธิ์เป็นกลาง

★ ภายในเตาไมโครเวฟ

- ทำความสะอาดภายในเตาไมโครเวฟและฝาปิดหลอดนำคลื่นไมโครเวฟด้วยผ้าชุบน้ำอุ่นบิดหมาด

เช็ดคราบอาหารออกให้หมด ซึ่งอาจจะก่อให้เกิดความร้อนมากขึ้นภายในเตา

ห้ามใช้แปรงที่มีขนแข็งหรือที่ขูดโลหะที่มีคมทำความสะอาดกระจกของประตูเตาไมโครเวฟเนื่องจากอาจจะทำให้พื้นผิวเกิดการขีดข่วน ซึ่งอาจจะทำให้กระจกแตกได้

ทำความสะอาดวงแหวนหมุนและถาดแก้วด้วยน้ำยาทำความสะอาดที่มีฤทธิ์เป็นกลางและเช็ดให้แห้งก่อนนำเข้าไปในเตาไมโครเวฟ



อาจมีกลิ่นไม่พึงประสงค์เนื่องจากใช้งานมาเป็นระยะเวลานาน สามารถขจัดกลิ่นได้โดยวิธีต่อไปนี้ :

1. นำมะนาวที่หั่นเป็นแว่นหลายๆ ชั้น หรือน้ำมะนาว 1 ช้อนโต๊ะใส่ลงในแก้ว วางในเตาอบไมโครเวฟ แล้วให้เตาอบทำงานเต็มกำลังเป็นเวลา 2-3 นาที
2. นำน้ำชาดำ 1 แก้ว วางในเตาอบไมโครเวฟ แล้วให้เตาอบทำงานเต็มกำลังเป็นเวลา 2-3 นาที
3. นำเปลือกส้มวางในเตาอบไมโครเวฟ แล้วให้เตาอบทำงานเต็มกำลังเป็นเวลา 1 นาที

คำแนะนำในการปรุงอาหาร

● การปรุงอาหารด้วยเตาไมโครเวฟ

★ การวางอาหาร

- วางส่วนที่หนาไว้ด้านนอก และส่วนที่บางไว้ด้านใน (จากตรงกลาง)

★ การตั้งเวลาการปรุงอาหาร

- ตั้งเวลาปรุงอาหารที่เร็วกว่าในครั้งแรกเพื่อดูว่าอาหารสุกดีหรือไม่ ถ้าไม่ ให้ตั้งเวลานานขึ้นเพื่อปรุงอาหารต่อไป ถ้าหากตั้งเวลาปรุงอาหารที่นานกว่าตั้งแต่แรกอาจจะทำให้อาหารไหม้

★ การห่อคลุมอาหาร

- ห่ออาหารด้วยฟิล์ม, ฝาปิดหรือผ้าเช็ดปากที่สามารถใช้ร่วมกับเตาไมโครเวฟ ตรงนี้เป็นการป้องกันการกระเด็นของของเหลวและทำให้อาหารสุกอย่างทั่วถึง

★ การห่ออาหารบางส่วน

- การห่ออาหารบางส่วนจะทำให้ส่วนที่บางของอาหารสุกมากเกินไป ห่อส่วนเหล่านี้ด้วยฟอยอลูมิเนียมสำหรับการละลายน้ำแข็ง

★ การคนอาหาร

- ถ้าจำเป็น ให้คนอาหารหนึ่งหรือสองครั้งในระหว่างการปรุง

★ การกลับด้านอาหาร

- ในขณะที่ปรุงอาหารอย่างเช่น น่องไก่, แฮมเบอร์เกอร์หรือสเต็ก ให้กลับด้านอาหารเมื่อผ่านการปรุงอาหารในครั้งแรกเพื่อทำให้อาหารสุกอย่างทั่วถึง

★ การนำอาหารวางในเตาไมโครเวฟอีกครั้ง

- ตำแหน่งของอาหารจะต้องได้รับการเปลี่ยนในระหว่างการปรุงอาหาร เพื่อทำให้อาหารสุกอย่างทั่วถึง ยกตัวอย่างเช่น การเปลี่ยนตำแหน่งระหว่างส่วนของภายนอกและภายใน หรือระหว่างด้านบนและด้านล่าง

★ การพักอาหารหลังปรุงเสร็จใหม่

- เมื่ออาหารปรุงเสร็จแล้ว พักอาหารไว้ในเตาไมโครเวฟสักพัก ควรทำการปิดบางส่วน ถ้าเป็นไปได้ ให้นำอาหารออกมาจากเตาและคนให้ทั่ว

★ การตรวจสอบว่าอาหารสุกหรือไม่

- อาหารสุกหรือไม่ได้รับการตัดสินจากสีและความแข็งของอาหาร ยกตัวอย่างเช่น ให้สังเกตว่าตรงนี้มีไอน้ำเกิดขึ้นจากชิ้นอาหารทั้งหมดหรือที่ขอบของอาหาร หรือดูว่าข้อต่อของสัตว์ปีกนั้นสามารถฉีกออกได้อย่างง่ายดายหรือไม่ หรือดูว่าตรงนี้มีเลือดในชิ้นเนื้อหรือสัตว์ปีกหรือไม่ หรือดูว่าเนื้อปลายังดูใสอยู่หรือไม่และสามารถตัดด้วยมีดหรือส้อมได้ง่ายหรือไม่

★ ไอน้ำจำนวนมาก

- ตรงนี้เป็นเรื่องปกติที่เกิดไอน้ำจำนวนมากในระหว่างที่เตาไมโครเวฟทำงานซึ่งทำให้ไอน้ำในอาหารละลายออกมา กลาวอย่างง่าย ๆ คือ อาหารที่มีการห่อหุ้มจะมีไอน้ำน้อยกว่าอาหารที่ไม่ได้มีการห่อหุ้ม ดังนั้น ภายในเตาไมโครเวฟจะต้องมีการระบายอากาศที่ดี

- ★ กระดาษที่สามารถใช้กับเตาไมโครเวฟ
 - ก่อนใช้กระดาษหรือภาชนะอื่นๆ แยกกระดาษออกจากเซรามิคด้านล่างด้วยภาชนะทนความร้อนอย่างเช่น ถาดเซรามิค เพื่อป้องกันไม่ให้ด้านล่างของภาชนะเซรามิคแตกเนื่องจากเกิดความร้อนมากเกินไป
 - กระดาษจะต้องไม่ใช้งานภายในเตาไมโครเวฟนานเกินไป
- ★ กระดาษกันเสียที่สามารถใช้กับเตาไมโครเวฟ
 - เมื่อปรุงอาหารที่มีไขมัน ควรใช้กระดาษกันเสียที่ไม่สัมผัสกับอาหาร เนื่องจากอาหารอาจจะละลายได้
- ★ เครื่องครัวที่ทำจากพลาสติก
 - เครื่องครัวที่ทำจากพลาสติกบางชิ้นสามารถใช้งานร่วมกับเตาไมโครเวฟอาจจะไม่สามารถใช้ในการปรุงอาหารที่มีน้ำมันหรือน้ำตาลมากเกินไป
- ★ เครื่องครัวที่ทำจากพลาสติก
 - เครื่องครัวที่ทำจากพลาสติกที่สามารถใช้งานร่วมกับเตาไมโครเวฟอาจจะไม่สามารถใช้ในการปรุงอาหารที่มีน้ำมันหรือน้ำตาลมากเกินไป

● วิธีการละลายอาหารแช่แข็ง

- ★ เสติก
 - ห่อส่วนปลายที่บางของเสติกด้วยฟอยอลูมิเนียม
 - วางเสติกไว้บนกระดาษโดยส่วนที่บางที่สุดให้อยู่ตรงกลาง ตรวจสอบว่าเสติกถูกหั่นแยกทั้งหมด
 - กลับด้านเสติกเมื่อผ่านการละลายน้ำแข็งของอาหารในครั้งแรก และห่อเสติกในส่วนที่น้ำแข็งละลายแล้วด้วยฟอยอลูมิเนียม
 - นำเสติกกลับไปวางไว้บนกระดาษ และปิดประตูเตาไมโครเวฟและเริ่มการละลายอาหารแช่แข็งต่อ
 - เมื่อการละลายอาหารแช่แข็งเสร็จสิ้น พักเสติกเอาไว้ในฟอยอลูมิเนียมประมาณ 5 – 10 นาที
- ★ เนื้อวัว (เนื้อหั่นเป็นชิ้น)
 - ห่อขอบของเนื้อวัวด้วยฟอยอลูมิเนียม และวางบนกระดาษ
 - กลับด้านเนื้อวัวเมื่อผ่านการละลายน้ำแข็งของอาหารในครั้งแรก นำส่วนที่ละลายแล้วออก และห่อเนื้อวัวอีกครั้ง
 - ปิดประตูเตาไมโครเวฟและเริ่มการละลายน้ำแข็งต่อ
 - เมื่อการละลายอาหารแช่แข็งเสร็จสิ้น พักเนื้อวัวเอาไว้ในฟอยอลูมิเนียมประมาณ 5 – 10 นาที
- ★ การย่างเนื้อสัตว์ (เนื้อวัว/หมู/เนื้อแกะ)
 - ห่อขอบของเนื้อด้วยฟอยอลูมิเนียม
 - วางบนกระดาษ
 - กลับด้านเนื้อเมื่อผ่านการละลายน้ำแข็งของอาหารในครั้งแรก และห่อเนื้อในส่วนที่ละลายแล้ว
 - ปิดประตูเตาไมโครเวฟและเริ่มการละลายน้ำแข็งต่อ
 - เมื่อการละลายอาหารแช่แข็งเสร็จสิ้น พักเสติกเอาไว้ในฟอยอลูมิเนียมประมาณ 10 – 30 นาที
- ★ สัตว์ปีก
 - แกะห่อของสัตว์ปีกหลังจากซื้อมา และห่อปีกและเท้าของสัตว์ปีกด้วยฟอยอลูมิเนียม
 - วางบนกระดาษโดยให้หน้าออกคว่ำลง
 - กลับด้านสัตว์ปีกเมื่อผ่านการละลายน้ำแข็งของอาหารในครั้งแรก และห่อส่วนที่ละลายแล้ว
 - ปิดประตูเตาไมโครเวฟและเริ่มการละลายน้ำแข็งต่อ
 - เมื่อการละลายอาหารแช่แข็งเสร็จสิ้น พักเสติกเอาไว้ในฟอยอลูมิเนียมประมาณ 10 - 30 นาที
- ★ ชิ้นส่วนของไก่ (ปีกและน่อง)
 - ห่อส่วนที่เป็นกระดูกด้วยฟอยอลูมิเนียม
 - วางบนกระดาษ
 - กลับด้านของชิ้นส่วนไก่เมื่อผ่านการละลายน้ำแข็งของอาหารในครั้งแรก และห่อส่วนที่ละลายแล้ว
 - ปิดประตูเตาไมโครเวฟและเริ่มการละลายน้ำแข็งต่อ
 - เมื่อการละลายอาหารแช่แข็งเสร็จสิ้น พักเสติกเอาไว้ในฟอยอลูมิเนียมประมาณ 5 – 30 นาที

เหตุการณ์ปกติและการแก้ไขปัญหา

● ข้อควรระวังไว้ล่วงหน้า



โปรดระวังการกระจายของคลื่นไมโครเวฟ
 ตรงนี้จะมี การกระจายของคลื่นไมโครเวฟและแรงดันไฟฟ้าสูงภายในเตาไมโครเวฟ
 เพื่อลดความเสี่ยงในการเกิดอันตรายกับสุขภาพห้ามแกะเตาไมโครเวฟด้วยตัวเองยกเว้นช่างผู้ชำนาญงาน
 และห้ามอยู่ในบริเวณของตัวสร้างคลื่นไมโครเวฟหรือตัวกระจายคลื่น

1. ถ้าหากประตูเตาไมโครเวฟหรือผนังของประตูชำรุด ห้ามใช้เตาจนกว่าได้รับการซ่อมโดยช่างผู้ชำนาญงาน
2. ถ้าหากเตารับและฟิวส์อยู่ในสภาพการใช้งานที่ไม่ดี โปรดติดต่อศูนย์บริการหลังการขายของ FOTILE หรือช่างที่มีคุณสมบัติเหมาะสม
3. เฉพาะช่างผู้ชำนาญเท่านั้น ห้ามให้บุคคลอื่นทำการตรวจดูเตาไมโครเวฟ รวมถึงการแกะตัวเครื่อง

● เหตุการณ์ปกติ

1. การรับสัญญาณของวิทยุและโทรทัศน์อาจจะถูกแทรกเมื่อเตาไมโครเวฟทำงานอยู่
 ตรงนี้เหมือนกับคลื่นแทรกของอุปกรณ์ไฟฟ้าขนาดเล็ก อย่างเช่น เครื่องผสมอาหาร เครื่องดูดฝุ่นและพัดลม
 ตรงนี้เป็นเรื่องปกติ
2. ถึงแม้ว่าเตาไมโครเวฟจะไม่ชำรุดในระหว่างการใช้งานโดยที่ไม่มีอาหารอยู่ในเตาอย่างรวดเร็ว
 ผู้ใช้งานควรหลีกเลี่ยงอย่าให้เกิดขึ้น
3. เตาไมโครเวฟควรได้รับการทำความสะอาดเป็นประจำ โดยเฉพาะเมื่อใช้ฟังก์ชันไมโครเวฟหรือการย่าง
 เนื่องจากจะมีน้ำมันติดอยู่บนผนังด้านบนภายในเตาไมโครเวฟและผนังด้านข้างซึ่งทำให้เกิดควันได้
4. อุณหภูมิภายในเตาไมโครเวฟจะเพิ่มสูงขึ้นถ้าหากใช้แมกนีตรอนเป็นเวลานาน เพื่อป้องกันการเกิดแมกนีตรอน
 เตาไมโครเวฟจะต้องปิดการทำงานโดยอัตโนมัติและกลับมาทำงานต่อใหม่อีกครั้งทันที ตรงนี้เป็นเรื่องปกติ

● การแก้ไขปัญหาเบื้องต้น

ปัญหา	สาเหตุที่น่าจะเป็น	การแก้ไขปัญหา
หน้าจอ LED ไม่แสดงค่า	ปลั๊กไฟเสียบไม่แน่น	ถอดปลั๊กและเสียบปลั๊กใหม่อีกครั้งหลังจากผ่านไป 10 วินาที
	ฟิวส์ใหม่หรือเบรกเกอร์ของวงจรไฟฟ้าทำงาน	ติดต่อฝ่ายบริการลูกค้าของ FOTILE
	เต้าเสียบมีปัญหา	ทดสอบเต้าเสียบด้วยเครื่องใช้ไฟฟ้าอื่นๆ
	อยู่ในโหมดแอสแตนบายด์	กดปุ่มใดปุ่มหนึ่งเพื่อออกจากโหมดแอสแตนบายด์
เตาไมโครเวฟไม่เริ่มทำงาน	ประตูเตาไมโครเวฟปิดไม่สนิท	ปิดประตูไมโครเวฟให้สนิท
	ยังไม่ได้กดปุ่ม “เริ่มต้นOK”	กดปุ่ม “เริ่มต้น”
	โปรแกรมอื่นถูกเลือกใช้อยู่	กดปุ่ม “Pause/Cancel” เพื่อยกเลิกโปรแกรมที่เลือกไว้และเลือกโปรแกรมใหม่
	เลือกโปรแกรมไม่ถูกต้อง	เลือกโปรแกรมให้ถูกต้องตามที่ระบุไว้ในคู่มือการใช้งาน
	บังเอิญไปกดปุ่ม “Pause/Cancel”	เลือกโปรแกรมการปรุงอาหารให้ถูกต้อง

FOTILE

USER'S HANDBOOK

IMPORTANT SAFETY INSTRUCTIONS
READ CAREFULLY AND KEEP FOR
FUTURE REFERENC

MICROWAVE OVEN

HW25800K-01AG
HW25800K-03G/03BG
HW25800K-C2G



Thank you for choosing our products please read the handbook carefully before use and keep it for future reference.

CONTENTS

Warning and Safety Instructions	1
Important safety instructions.....	1
Precautions	1
Applicable Utensils	2
Avoid Fire Explosion and Scalding.....	4
Packing List.....	5
Specification and Structure of Microwave Oven	6
Installation	7
Precautions	7
Installation Steps	8
Operation Instruction	8
Navigation	8
Initial Use	9
Microwave and Grill	9
Defrost Function	9
Control Panel	10
Cleaning and Maintenance	18
Cooking Tips	19
Cooking by Microwave.....	19
Method of Defrosting Foods	20
Normal Phenomena and Trouble Shooting	21
Precautions	21
Normal Phenomena	21
Trouble Shooting	21

This manual contains the information updated till the time when it is printed. We keen on technical innovation, we will reserve the rights to improve or modify the product and user's manual without any prior notices. Some of the illustrations in this manual are for reference purpose only and subject to the actual products if there are any differences.

Warning and Safety Instructions

● Important safety instructions

- **WARNING:** Accessible parts may become hot when grill is in use. Children should be kept away.
- **WARNING:** Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similar qualified persons in order to avoid a hazard.
- **WARNING:** If the door or door seals are damaged, the oven must not be operated until it has been repaired by a competent person;
- **WARNING:** It is hazardous for anyone other than a competent person to carry out any service or repair operation that involves the removal of a cover which gives protection against exposure to microwave energy and high voltage;
- **WARNING:** Liquids and other foods must not be heated in sealed containers since they are liable to explode;
- **WARNING:** Only allow children to use the oven without supervision when adequate instructions have been given so that child is able to use the oven in a safe way and understands the hazards of improper use;
- The appliance is not intended for use by persons (including children) with reducing physical sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities.
- Contact your local government for information regarding the collection systems available.
- If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being.
- When replacing old appliances with new ones, the retailer is legally obligated to take back your old appliance for disposing at least free of charge.










● Precautions






1. Please read this user's manual carefully before initial use.
2. This appliance is for residential use only to cook, defrost, reheat and to grill food. Any other usage is not supported by the manufacturer and could be dangerous. The manufacturer cannot be held liable for damage caused by improper or incorrect use of the appliance.
3. The appliance is not intended for using by children or the disabled person unless they are supervised or properly instructed.
4. Make sure that the actual voltage and frequency are accorded with the ones clarified in this User's Manual to avoid any possible damages to the oven and be sure the unit is safe grounded.
5. Make sure that your oven is connected to a standard power socket with safe grounding to avoid electric shock.
6. Place the oven horizontally in a place of well ventilation and without the risk of corruption. It should stay away from high temperature and steam.
7. Place the oven as far as possible from TV set, radio and antenna to avoid any interference. A minimum distance of 5 meters is recommended.

8. Installation and repairs may only be carried out by a suitably qualified and competent person in accordance with national and local safety regulations. Repairs and other work by unqualified persons could be dangerous. The manufacturer cannot be held liable for unauthorized work.
9. Never open the casing of the appliance. Tampering with electrical connections or components and mechanical parts is highly dangerous and can cause operational faults or electric shock.
10. Do not block the ventilation hole of the oven to ensure well ventilation.
11. Do not have the oven working without putting any food inside, which may damage the appliance. After using, put a full glass of water on the glass tray in order to avoid any damage to the appliance.
12. Before serving, remember to allow a sufficient standing time and then always check the temperature of the actual food itself after taking it out of the microwave. The temperature of the container is not an indication of the temperature of the food or liquid in it.
13. Never put regular mercury or liquid thermometer into the oven for heating and measuring, since it's liable to sparkle or do damage to the appliance. Interrupt the cooking process before check food temperature.
14. Do not use the microwave if
 - the door is warped.
 - the door hinges are loose.
 - holes or cracks are visible in the casing, the door or the oven interior walls.
 Operating the appliance with this type of damage will result in microwave leakage and present a hazard to the user.
15. Please do as follows to keep the glass tray from damage:
 - Do not wash the tray with water until it's cool.
 - Do not put red-hot food or utensils on cool tray.
 - Do not cold food or utensils on red-hot tray.
 - Do not put anything exceeding 5Kg on the tray.
 - Do not use the oven for food storage purpose.
 - Only use accessories which are authorized by FOTILE.

● **Applicable Utensils**

- ★ Only use utensils that are suitable for using in microwave ovens:
- ★ How to check whether the utensils are suitable for microwave oven.
 - Tips  Put the utensil into microwave oven along with a glass of 300ml cold water, and choose MICROWAVE mode to cook for 1 minute. It is the applicable utensil if it keeps cool while water gets hot. On the contrary, it cannot be used in microwave oven if the utensil gets hot, that means it has absorbed a certain content of microwaves. This method is inapplicable for plastic utensils.
- ★ Improper utensils used in microwave oven would not only bring bad taste to the food, but also do damage to the oven or the utensil. Please take the following table for reference.

Type of Utensil	Microwave	Grill	Grill Combi
 Heat-resistant Glass Vessels	Applicable ⚠ When cooking jams, please use super heat-resistant glass vessels that can endure sudden cold or hot	Inapplicable	Inapplicable
 Non-heat-resistant Glass Vessels	Inapplicable ⚠ Including cut-glass and tempered glass	Inapplicable	Inapplicable
 Heat-resistant Plastic Vessels	Applicable ⚠ Please use the vessels marked "For Microwave Oven Use". ⚠ Pay attention to those plastic covers which are not heat-resistant. ⚠ Avoid using covers with good air-tightness ⚠ Never cook food containing high content of oil or sugar, which creates abundant heat.	Inapplicable ⚠ Plastics for grill purpose is applicable.	Inapplicable
 Non-heat-resistant Plastic Vessels	Inapplicable ⚠ Never use any materials that can be deteriorated by microwave, such as polythene, melamine, hydroxybenzene and carbamide resin, etc. ⚠ Foam tray is applicable only for defrosting fresh food	Inapplicable	Inapplicable
 Lacquer wares	Inapplicable ⚠ The painting may fall off or rupture.	Inapplicable	Inapplicable
 Ceramic Vessels	Applicable ⚠ Vessels with paintings or gold/silver decorations is not applicable since it tends to cause scratches and sparkles.	Applicable ⚠ Never use ceramics with painting inside, which will fall off.	Applicable

Type of Utensil	Microwave	Grill	Grill Combi
 <p>Vessels Made of Metals (such as Aluminum)</p>	<p>Inapplicable</p> <p>⚠ Never use metal meshwork or metal bunches which may cause sparkles.</p> <p>⚠ Even the metal painting plate for microwave oven use is not applicable.</p>	<p>Applicable</p> <p>⚠ Do not use the vessel with resin handle.</p> <p>Inapplicable</p>	Inapplicable
 <p>Vessels Made of Wood, Bamboo and Paper</p>	<p>Inapplicable</p> <p>⚠ These kind of vessels are flammable.</p>	<p>Inapplicable</p> <p>⚠ Paper vessels made by heat-resistant processing are applicable.</p>	Inapplicable
 <p>Grill Rack</p>	Inapplicable	Applicable	Applicable
 <p>Cling Film for Microwave Purpose</p>	<p>Applicable</p> <p>⚠ Foods containing high content of oil are not applicable.</p>	<p>Inapplicable</p> <p>⚠ It will melt in high temperature.</p>	Inapplicable
 <p>Aluminum Foil</p>	<p>Inapplicable</p> <p>⚠ It's available if making use of the reflective character of microwave to defrost fresh foods.</p>	<p>Applicable</p> <p>⚠ Pack foods in aluminum foil to grill.</p>	Inapplicable

● **Avoid Fire, Explosion and Scalding**

1. In order to avoid the inside of oven catches fire, please do as follows:
 - a. Never sealed the foods before cooking.
 - b. Before cooking the food which packed by paper or plastic bag, please take the binding away.
 - c. When heating food in plastic or paper containers, keep an eye on the oven due to the possibility of ignition;
 - d. When cooking foods with one-off utensils, please pay attention to the status inside oven.
 - e. Never cook alcohol, oil or fried foods, for it is not easy to control the temperature of oil.
 - f. When cooking small quantity of food, care enough to avoid the hazard of fire due to overheating.
 - g. Each time after cooking, use a piece of wet cloth and dry cloth one after another to wipe off the offscourings or oil on the mica or walls of the oven, in order to avoid any black smoke or fire.
 - h. When the cooking utensil catches fire, switch off the appliance immediately. Effective extinguishing measures must be taken at once, such as keep the door closed.

- i. Exercise caution when cooking or reheating food with a high sugar content. If heated for too long, the sugar may caramelize or ignite.
 - j. To avoid fuelling and flames, do not open the oven door if smoke occurs in the oven interior. Interrupt the process, turn off the oven and remove the plug. Do not open the door until the smoke has dispersed.
 - k. The contents of feeding bottles and baby food jars shall be stirred or shaken and the temperature checked before consumption, in order to avoid burning;
2. In order to avoid explosion, please do as follows:
 - a. Never cook foods with sealed vessels, such as nursing-bottle with lid or nipple.
 - b. When cooking liquid, please use a broad rim vessel, and reserve enough space in the vessel for boiling.
 - c. Microwave heating of beverages can result in delayed eruptive boiling, therefore care must be taken when handling the container;
 - d. Before cooking any round or columniform food such as potatoes, chestnuts or sausages, please use knife or fork to perforate in order to avoid explosion.
 - e. Do not take the cooked eggs or liquid out of oven immediately to avoid delaying spurting. In order to avoid explosion, never cook fresh or cooked eggs with eggshell.
 - f. Do not take the poached egg or rice glue ball out of oven immediately to avoid explosion. Wait a moment after opening the door.
 3. In order to avoid scalding of sudden boiling, please do as follows.
 - a. Take cooked food out of oven with gloves instead of bare hands to avoid scalding by steam.
 - b. When quartz tube is red-hot or the food is just done, do not touch the upper board of the cavity. Thus cooking food in GRILL mode, use gloves only to overturn the food since the temperature inside is very high.
 - c. In order to avoid scalding the content of nursing-bottles or baby food cans shall be stirred or shaken and the temperature shall be checked before consumption.


Packing List

1. Take the packing material out of oven, and examine carefully whether the oven is intact.
 - a. Is the oven impacted or pressed by heavy object?
 - b. Is the oven door flat and switch unhindered?
 - c. Is the metal meshwork on door curved or deformed?
 - d. Is the power cord damaged or loose?
 If you find any one of the above happens, please contact FOTILE authorized service people.
2. Packing list

Name	Quantity
Microwave Oven	1
User's Manual	1
Cruciform Slot Round Weeden Screws M4 x 24 black zinc galvanized	4
Grill Rack	1
Glass Tray	1
Turntables Shaft	1

Specification and Structure of Microwave Oven

Model	HW25800K-01AG	HW25800K-03G/03BG	HW25800K-C2G
Rated Voltage	220-240V 50Hz	220-240V 50Hz	220-240V 50Hz
Rated Input Power	1150W-1350W(Microwave) 750W-850W (Grill)		
Rated Output Power(Microwave)	800W		
Rated Frequency(Microwave)	2450MHz		
External Dimension(L x W x H)	595mm x 385mm x 368mm	595mmx385mmx 416mm	
Oven Capacity	25L		
Accessory for Heating Only	Special Glass Tray		
Net Weight	20kg	22kg	20kg




● Illustration

- ① Safety interlock system: To ensure the oven does not work unless the door is closed.
- ② Turnable shaft: To make the glass tray turning.
- ③ Turnable ring assembly: support the glass turntable and rotate along its path.
- ④ Oven cavity.
- ⑤ Control panel: Please refer to the description for control panel.
- ⑥ Observation window: To watch the food inside through a metal shielding meshwork.
- ⑦ Glass tray: The vessel containing food is put on the tray, which turns to get the food heated uniformly.
- ⑧ Grill rack: Only use for grill or combined modes.
- ⑨ Mica: To avoid vapor or grease entering into the tube the mica must not be removed, which could effect the operation of microwave.


Installation

● Precautions

Microwave oven must be installed one the 3 cupboards as demonstrated below (ground cupboard, wall cupboard, and high cupboard), which has ventilation channels. If the user does not install the oven in these 3 types of cupboards, FOTILE is not responsible for any accident caused.



● Installation Steps



1. Push the microwave oven into the cabinet.
2. The distance for the microwave oven frame and the carbinet is 8mm.
3. Fixing the microwave oven in the cabinet by the four screws which type are ST4 x 25.

Operation Instruction

★ Operation Instruction for HW25800K-03G/03BG/01AG

● Navigation

1. Plug in the power supply.
2. Put food onto the glass tray, and close the oven door. Be careful that never switch on the appliance without food inside, in order to avoid damage to the oven.
3. Choose cooking mode.
 - a. The grill rack must be taken out if "Microwave" function is chosen.
 - b. Make sure that the distance between food and heating tube must be 5cm at least if combination function is chosen. The food must be turned over during operation.

4. Set cooking time.
5. The microwave oven starts cooking with set program. The program will pause if the microwave oven door is opened, on the contrary the microwave oven will resume operation after "Start" button is pressed.
6. It's definitely suggested to wear glove to take or turn over food. Do not touch the walls of the cavity.
7. In combination mode or grill mode, do not touch the top, the door, and both sides of the oven because they are very hot. Only the control panel can be touched.
8. When food is cooked, the buzzer beeps for 3 times before the oven stops working, and the indication light is off.

● Initial Use

When using microwave oven for the first time, you may catch bad smell and even see white smoke from the oven. It's a normal phenomenon, and after using it for several times, it will not happen again. Be sure that the door and window open in your room to keep good ventilation. Anyway, you can take the following steps to avoid this phenomenon:

1. Before initial use choosing GRILL mode to dry cook for several times.



Dry cook is only available in GRILL mode. Not for MICROWAVE mode or a combination mode.

2. Before initial use choosing MICROWAVE mode and putting a glass of water on the glass tray to cook in high power for several times.

● Microwave and Grill

1. Microwave is penetrable. It can penetrate into the food and cook the food in a short time without losing water of the food. However, it cannot turn the surface of food brown and the food crispy.
2. The energy of grill function comes from radiation of the heating tube, which can make the surface of food brown. But if the food is too thick, it could be possible that the inside of food remains uncooked while its surface is charred. Therefore, the combination of microwave and grill can take both advantages to make the food look good and taste good.



Do not use microwave when the oven is empty-loaded. And never use metal utensils that may cause spark or potential risks.

● Defrost Function

It's one of the characteristics of microwave oven to defrost food. Microwave defrosts is quicker than electric ovens and safer than defrosting at room temperature, since no harmful bacteria will breed in microwave. Turn the function knob to choose defrost function, and then turn the timer knob to set defrost time according to the weight of food. As microwave can not penetrate 4cm from one side, you have to turn over the food from time to time if it's large and thick. It's suggested to take out the defrosted part and make the rest of food easier to defrost; otherwise it's possible that the surface of food gets defrosted, while its inside is still frozen.

1. It's very necessary to turn over the food during defrosting in order to ensure the food defrosted averagely.

2. Defrosting is done when the food can be cut off by knife.
3. Defrosting take longer time than normal cooking.
4. The defrosted food should be consumed as soon as possible. Do not put it into refrigerator again.

● Control Panel


1. Switch on the appliance. The LED flashes for 3 times to display all functions, then ":" flashes. Choose time or cooking functions.


2. Clock Setting (24 hours).


When ":" displays, press "preset clock" key, and operate the "Timer /Weight/Auto Menu" knob/key to confirm hour. Press "preset clock" key, and operate the "Timer /Weight/Auto Menu" knob/key to confirm minute. Finally, press "preset clock" key to confirm the above steps. Clock setting is completed, and current time is displayed. To reset or change the time, please repeat the above steps.


3. Power Setting.


Press "Microwave" button each time, "100P", "80P", "60P", "40P", "20P" will display in turn. Operate the "Timer /Weight/Auto Menu" knob/key to set time, and press " Start " to start cooking with set power.

100P  : 100% microwave (high power). Boiling water, cooking fresh fruit, vegetables and candied fruit.

80P  : 80% microwave (high-medium power). Cooking fish, seafood, meat, poultry, eggs and cakes.

60P  : 60% microwave (medium power). Cooking cakes, boiling food, melting butter and chocolate.

40P  : 40% microwave (medium-low power). Cooking cuts of meat, stewing soup, softening butter.

20P  : 20% microwave (low power). Keeping warm, softening ice cream.

4. Quick Start.

Press "Express" each time, and LED displays "0:30", "1:00", and "1:30" sequentially.

0:30: Default time is 30 seconds.

1:00: Default time is 1 minute.

1:30: Default time is 1 minute and 30 seconds.

Press " Start " to start cooking with high power in chosen time.

5. Light Wave Grill

Press " Grill " key, and then operate the "Timer /Weight/Auto Menu" knob/key to set time. Press "Start" to cook in chosen time. "Light Wave Grill" function is for the purpose of cooking sliced meat such as beefsteak, pork steak, barbecue, sausage and chicken wings. It is also applicable for cooking sandwich and making food crispy.

6. Microwave + Grill (Combination)

Press "Grill combi" key each time, and LED displays "Grill combi1", "Grill combi2" and "Grill combi3" sequentially.

Grill combi1: 30% cooking time in microwave, and 70% cooking time in grill, best for grill, recommended for western-style food such as beefsteak.

Grill combi2: 55% cooking time in microwave, and 45% cooking time in grill, relatively quicker in cooking, recommended for a whole piece of poultry such as chicken, duck and goose.

Grill combi3: 70% cooking time in microwave, and 30% cooking time in grill, quickest in cooking, recommended for a whole piece of poultry such as chicken, duck and goose.

When the combination function is chosen, operate the "Timer /Weight/Auto Menu" knob/key to set time. Press "Start" to cook in chosen time.



In combination mode, all heating elements including grill rack and cooking utensils are very hot. Be careful when taking foods out of oven you can use thick cloth or special gloves for microwave oven purpose in order to avoid scalding.

Pre-heating is unnecessary in "Grill" mode.

7. Auto Defrost

Press "Auto Defrost", and LED displays "Defrost Meat", "Defrost Poultry" and "Defrost Seafood" sequentially.

Defrost Meat: for defrosting meat, with weight ranging from 0.1Kg to 2.0Kg.

Defrost Poultry: for defrosting poultry, with weight ranging from 0.2Kg to 3.0Kg (for HW25800K-01AG) 0.1Kg to 2.0Kg (for HW25800K-03G/03BG).

Defrost Seafood: for defrosting seafood, with weight ranging from 0.1Kg to 0.9Kg.

When the defrost function is chosen, operate the "Timer /Weight/Auto Menu" knob/key to set the weight. Press "Start" when the program detects that the food needs to be turned over, the buzzer sounds twice a second to remind you.

8. Pause/Cancel

Press "Pause/Cancel" , the operation of setting power, cooking time or defrost time can be canceled. When the oven is working, "Pause/Cancel" one time or open the oven door, the oven will pause; press the button twice, the program is cancelled.

9. Adjust the Auto Menu by rotating the coder leftward.

A.1 Rice: for cooking rice with weight ranging from 0.15Kg to 0.6Kg (for HW25800K-01AG) 0.1Kg to 0.5Kg (for HW25800K-03G/03BG);

A.2 Fresh Vegetable: for cooking vegetables with weight ranging from 0.1Kg to 0.5Kg (for HW25800K-01AG) 0.15Kg to 0.6Kg (for HW25800K-03G/03BG);

A.3 Popcorn: for making popcorn with corn weight ranging from 0.07Kg to 0.13Kg (for HW25800K-01AG) 0.1Kg (for HW25800K-03G/03BG);

A.4 Potato: for cooking 1,2 or 3 of potato (each weighing about 0.3Kg) (for HW25800K-01AG). Or with weight ranging from 0.15Kg to 0.6Kg (for HW25800K-03G/03BG);

A.5 Pizza: for heating pizza with a proximate weight ranging from 300g to 500g (for HW25800K-01AG) 150g to 300g (for HW25800K-03G/03BG);

A.6 Beverage: for heating 1 to 3 cup of liquid, (each capacity about 230ml) (for HW25800K-01AG), Or a cup of liquid weight 250g, 500g and 700g (for HW25800K-03G/03BG);

A.7 Fish: for cooking fish with weight ranging from 0.2Kg to 0.6Kg (for HW25800K-01AG) 0.1Kg to 0.5Kg (for HW25800K-03G/03BG) (this function will pause at the first half of working time, reminding user to turn over the fish);

A.8 Chicken: for grilling chicken with weight ranging from 0.8Kg to 1.4Kg(for HW25800K-01AG) 0.2Kg to 1.2Kg (for HW25800K-03G/03BG) (this function will pause at the first half of working time, reminding user to turn over the fish).



1. As the above programs are designed for foods within the temperature range 20°C-25°C, doneness of food is subject to the actual temperature. Please adjust time by yourself.
2. It's suggested to use cling film to cover food when cooking potatoes or fish, in order to avoid evaporation of water.
3. The taste is determined by the shape, weight and temperature of the food. When using "Auto Menu" function, please follow the above instructions, and make adjustment by yourself if the food is not well done.
4. Auto Menu
Doneness of food in "Auto Menu" function is determined by personal favor, size, quantity and placement of food and the working voltage. If the food is not well done, please adjust cooking time according to actual conditions.

10. Combination Cooking Program

Combination: For each time (or each phase), the maximum time to be set is 30 minutes(HW25800W-01AG) 60 minutes(for HW25800K-03G/03BG). Users can operate in 4 phases. For example, If you want to set 10 minutes of maximum microwave power plus 10 minutes of grill, you should follow this sequence: press "Microwave" button, the LED displays 100P; then turn "Timer /Weight/Auto Menu" knob to set the time as "10:00"; press "Grill" and turn "Timer /Weight/Auto Menu" knob; when the LED displays "10:00", press "Start" and the appliance will start cooking according to the program set. It will execute the first phase of program, until time decrease to "0"; then the second phase of program goes on until it ends.



Combination cooking program can not be set in "Auto Menu" mode.

11. Delay Time Function

When regular program and cooking time is set, the LED displays time, "8:28" for example, press "Preset clock" key button for 3 seconds, it's in delay time state now. When the defrost function is chosen, operate the "Timer /Weight/Auto Menu" knob/key to put into hour, and then press "Preset clock" key, and When the defrost function is chosen, operate the "Timer /Weight/Auto Menu" knob/key to set minute. Finally, press "Preset clock" key or waiting for 5 seconds later to start this function. The LED will display current time.

When checking delayed time, press "Clock Setting" button, and the LED will display delayed time. Release the button, the LED resumes current time.

When "Delay Time" function is activated:

- a. Press "Start" if you want to start cooking immediately.
- b. Press "Pause/Cancel" button if you want to cancel this function.

12. Reminder Tone

- a. The buzzer beeps for each valid operation. And low buzzer beeps for invalid operation.
- b. When each program ends, the buzzer will reminder for 3 times, and the LED displays "END". If the "Pause/Cancel" button is not pressed or the oven door not opened, the buzzer will beep every 3 minutes for reminding. When the door is opened, the LED will display ":" or current time.
- c. When the oven is cooking something, press "Microwave" button, and current cooking power will be displayed on LED. Release the button, the LED will display the residual time of cooking. Operation of the oven is not affected.

13. Child Lock Function

When LED displays " : " or current time, keep pressing "Pause/Cancel" button for 3 seconds. Child lock function is activated when the buzzer beeps and the LED " 🔒 " displays. The appliance can not be operated in this state. In order to unlock the oven, keep pressing "Pause/Cancel" button for 3 seconds, the buzzer beeps and the " 🔒 " disappears from LED.



1. In the process of setting functions, if no program is input for 2 minutes, it will display ":" or current time.
2. The "Start" button is activated in one of the following two conditions:
 - a. The oven door is closed in 2 minutes;
 - b. The "Pause/Cancel" button is press within 2 minutes, otherwise it's locked.

14. Fan Delay Function:

After the microwave oven stops working, the fan will continue to work for 2 minutes.

REMARK: this method can greatly reduce the rising of temperature of inner electric elements, by which to reach the target of prolong the lifespan of microwave oven. Also the temperature in the kitchen cabinet and be much safer.



15. The Door Control:

When the door is opened the light will be off. If the microwave oven is in the state of working, if the work stops it means the key of is pressed for once. After the door is opened, press the key of "OK" to restart.



1. After the cooking, the display screen shows: "End" and the buzzer beeps once every 3 minutes. To press any key to go back to the standby model
2. The key " ^ " or " v " , when setting time or weight, the intermittent press or non-stop press are both allowed.

★ Operation Instruction for HW2500K-C2G



● Power on

When power is on, the display screen is totally illuminated and after one second the buzzer beeps for one time, and then the display screen goes out.

To touch the power key and the display screen shows “⌚” the present time is 0:00, the clock begins to time and it goes into standby mode.

At any mode once touching the power key for once, the power is off.

At the model of power off, when touching the other keys except power key they will be invalid, and when touching one time it will go back to standby mode.

REMARK: at standby mode the display screen shows only present time and the “⌚” icon.

1. The setting of microwave oven cooking

- Function choosing: at standby mode when touching the “F” key, the display screen will show “⊙” (flashes), “P100” (flashes), “----” and the other basic function key to let illuminated.
- Firepower setting: the microwave firepower can be controlled by key of “^” or “v”. The microwave power cycling is “P100 ⇒ P80 ⇒ P60 ⇒ P40 ⇒ P20”. When the corresponding microwave power is set, touch the key “OK” to confirm, and the time begins from 0:10.
- Time setting: microwave working time can be set by the key “^” or “v”, and press key “OK” to confirm then the microwave starts working.

2. The setting of grilling cooking:

- Function choosing: at standby mode when touching the “Fi” key, the display screen will show “⌚” (flashes), “Grill” (flashes) and the other basic function key to let illuminated.
- Time setting: microwave working time can be set by the key “^” or “v”, and press key “OK” to confirm then the grilling cooking starts working.

3. The setting of baking and grilling combination cooking:

- Function choosing: at standby mode when touching the “iFi” key, the display screen will show “⊙” (flashes), “Co-1” (flashes), “baking and grilling combination 1” and the other basic function key to let illuminated.


B. Time setting: microwave working time can be set by the key “ ^ ” or “ v ” , and press key “ OK ” to confirm then the baking and grilling combination starts working.

(The operation procedures of combination 2 are the same as above, to touch the “F” key, the display screen will show “baking and grilling combination 2” and the time will be set.)

The baking and grilling combination 1: are suitable for cooking of flesh, a whole chicken or duck, food like this.


The baking and grilling combination 2: are suitable for cooking of cuisine occidental, grilled fillet steak and so on.

4. The setting of defrosting:

A. Function choosing: at standby mode when touching the “F” key, the display screen will show “  ” (flashes), “0.10” “kg”, “Defrost” and the other basic function key to let illuminated.

B. Weight setting: the defrost weight can be set by the key “ ^ ” or “ v ” , “0.10 ⇌ 0.20 ⇌ 0.30 …… 1.70 ⇌ 1.80” , and press key “ ^ ” or “ v ” to confirm then the defrost starts working.

5. The setting of clock function(24 hours system)


A. Function choosing: at standby mode when touching the “F” key, the display screen will show “  ” (flashes), “Hour”(flashes) “Clock” (flashes), and the other basic function key to let illuminated.

B. Hour setting: press the key “ ^ ” or “ v ” to adjust the “Hour” into the time needed to be set, and press key “ok” to confirm. The display shows (flashes) “minute” (flashes), “clock” (flashes), and then the other basic function key to let illuminated.

C. Minute setting: press the key “ ^ ” or “ v ” to adjust the “Hour” into the time needed to be set, and press key “ ok ” to confirm. Clock setting being finished, goes back to mode of standby.

F.E:

The present time is “0:00” , and the time needed to be set is “12:30” .

Touch “ F ” key for six times, and the display screen shows (flashes), “clock” (flashes) Press key “ ^ ” or “ v ” to adjust the “hour” to “12” , and press “OK” to confirm. “12:00” (“:00” flashes) and the others do not change. Then press key “ ^ ” or “ v ” to adjust the “minute” to “30” , and press “ OK ” to confirm, the display screen shows: “12:30” and “  ” , the setting of clock is finished.

6. The setting menu cooking:

A. Function choosing: At standby mode, touching the “  ” key to choose the menu.

B. Weight setting: press the key “ ^ ” or “ v ” to set the different weight for menu. Press key “OK”

(1). Rice: suit to cooking rice with weight from 0.15kg to 0.60kg;

(2). Vegetable: suit to cooking vegetable with weight from 0.10kg to 0.50kg;

(3). Meat: suit to cooking meat with weight from 0.20kg to 0.60kg(to turn over the food when the buzzer beeps);


(4). Pizza: suit to heat pizza with weight about 0.30kg/0.50;

(5). Beverage: suit to heat beverage or liquid with capacity of 230ml for 1-3 cups.

(6). Puffed rice: suit to puff corn with weight from 0.07kg to 0.13kg;

(7). Fish: suit to steam the fish with weight from 0.20kg to 0.60kg;

F.E: to cook rice of 0.30kg.

At the model of standby, to press the key “  ” , and the display shows "0.15kg", "kg", "rice"(flashes), and the other basic Function key to let illuminated.

Press the key “ ^ ” or “ v ” to set the weight of rice, and the weight set is 0.30kg. After the confirmation to the weight, Press key “OK” to confirm, the cooking of rice begins.(the setting of the other menu are similar with rice)



1. As the above programs are designed for foods within the temperature range 20°C-25°C, doneness of food is subject to the actual temperature. Please adjust time by yourself.

2. It is suggested to use special microwave vessel when cooking rice, in order to avoid evaporation of water or rice.





3. it's suggested to use cling film to cover food when cooking potatoes or fish, in order to avoid evaporation of water.



4. The taste is determined by the shape, weight and temperature of the food. When using "Auto Menu" function, please follow the above instructions, and make adjustment by yourself if the food is not well done.

5. Auto Menu

Doneness of food in "Auto Menu" function is determined by personal favor, size, quantity and placement of food and the working voltage. If the food is not well done, please adjust cooking time according to actual conditions.

7. The setting of child locks function:

Lock: at the mode of standby, to touch the key of “  ” for 3 seconds. The display will shows: present clock “  ” “  ” , and then the child lock is set successfully. At this moment all the keys are invalid except “  ” and “power” .

Unlock: at the mode of standby, to touch the key of “  ” for 3 seconds. The display will shows: present clock “  ” and then the child lock is set successfully.

8. The setting of multi section function:

When the multi section function is set, microwave, grilling, the baking and grilling combination 1 and baking and grilling combination 2 set can be set at multi section. It is forbidden to set P100. microwave, or grilling, or the baking and grilling combination 1 and baking and grilling Combination 2 at the same time. Multi section can be set as three sections at most.

F.E: to heat in different firepower when making soup.

(1). To set the first section: to set microwave P100 firepower for 6 minutes according to the microwave setting methods.(Don't press key "OK")

(2). To set the second section: to set microwave P40 firepower for 5 minutes according to the microwave setting methods.(Don't press key "OK")


(3). To set the third section: to set microwave P20 firepower for 4 minutes according to the microwave setting methods. Then press the key "OK" to start working.



REMARK: this function are used to the cooking the food need the adjustment of firepower like making soup, porridge, etc.

9. The setting of quick start:

At the mode of standby, to touch the key “ ^ ” or “ v ” , the time will increase for 30 seconds by one touch, the maximum time will be 10 minutes. After the setting of time, press the key of "OK" to confirm, and the microwave starts working. The Acquiescent firepower will be P100.

10. The function of cancel and pause:

When setting the function to press the key “  ” for once, the present function setting is cancelled and it goes back to standby mode.

After start working, to press the key “  ” for once, it will pause. Touching key "OK" to restart, or to touch the “  ” again to go back to standby mode directly.

11. Auto return function:

When setting functions, it will go back to standby mode when there is no any effective key operation.

12. Inquiry function:

When the machine is working, to touch the key "F" for once, and the display shows "⊖" the time on present clock, it will go back to working interface.

13. Fan delay function:

After the microwave oven stops working, the fan will continue to work for 2 minutes.

REMARK: this method can greatly reduce the rising of temperature of inner electric elements, by which to reach the target of prolong the lifespan of microwave oven. Also the temperature in the kitchen cabinet and be much safer.

14. The door control:

When the door is opened the light will be off. If the microwave oven is in the state of working, if the work stops it means the key of "C/⊖" is pressed for once. After the door is opened, press the key of "OK" to restart.



1. After the cooking, the display screen shows: "End" and the buzzer beeps once every 3 minutes. To press any key to go back to the standby model
2. The key "∧" or "∨", when setting time or weight, the intermittent press or non-stop press are both allowed.

Cleaning and Maintenance

Unplug this appliance before cleaning.

- ★ The oven should be cleaned regularly, Do not use a steam-cleaner to clean this appliance. Pressurized steam could reach the electrical components and cause a short circuit. If the food or liquids containing salt splash the cavity interior, wipe these away thoroughly to avoid corrosion on the cavity surface.
- ★ Failure to maintain the oven in a clean condition could lead to deterioration of the surface that could adversely affect the life of the appliance and possibly result in a hazardous situation;
- ★ Surface of Microwave Oven
 - Clean the surface with a wet cloth containing neutral detergent. Do not use any corrosive detergent or damaging tools.
- ★ Oven Door
 - Clean the doorframe, window, seal and adjacent parts with warm and wet cloth. Do not use any corrosive detergent.
- ★ Control Panel
 - Be careful when cleaning the control panel. Use a soft cloth with certain amount of water to clean it (if the panel gets wet, use a dry soft cloth instead). Do not scrape the panel or clean it with corrosive detergent.
- ★ Grill Rack
 - After using, clean the rack with neutral detergent.
- ★ Oven Cavity
 - Clean the cavity and the cover of wave-guide tube with wet warm cloth. Wipe off the food residue, which may cause partial overheating inside oven. Do not use harsh abrasive cleaners or sharp metal scrapers to clean the oven door glass since they can scratch the surface, which may result in shattering of the glass. Clean the turnable ring and glass tray with neutral detergent and dry them before putting back into oven.



Peculiar smell may exist in the oven after long-term usage. You can get rid of the smell by one of the following ways:

1. Put several slices of fresh lemon or spoons of lemon juice in a glass, and cook it in oven for 2-3 minutes with high microwave power.
2. Put a glass of black tea into oven, and cook it for 2-3 minutes with high microwave power.
3. Put some orange pericarp inside the oven, and cook for 1 minute with high power.

Cooking Tips

● Cooking by Microwave

- ★ Placement of food
 - Put the thick part outward, and the thin part inward (in the middle).
- ★ Setting Cooking Time
 - Set a short cooking time first to see whether the food is cooked well. If not, set longer time to continue cooking. If a long time is set at the beginning the food might be burnt.
- ★ Covering of Food
 - Cover the food with cling film, lid or napkin that are applicable for microwave. This could prevent splash of liquid and make the food cooked averagely.
- ★ Partial Wrapping of Food
 - Partial wrapping can keep the thin part of food from being overcooked. Wrap these parts with aluminum foil for defrosting.
- ★ Stirring of Food
 - If necessary, stir the food for one or two times during cooking.
- ★ Turning of Food
 - When cooking foods such as chicken leg, hamburger or steaks, turn the food over when it's half done in order to make it cooked averagely.
- ★ Re-placement of Food
 - The position of food shall be changed during cooking, in order to make the food averagely cooked. For example, exchange the positions between the outward part and inward part, or between the upper part and lower part.
- ★ Keeping of Food
 - When the food is cooked, keep it in the oven for a while, better with some coverings. If possible, take the food out of oven and stir it.
- ★ Checking Doneness
 - Doneness of food can be judged by the color and hardness of food. For example, observe whether there's vapor rising from the whole piece instead of part or edge of food, or whether the joint of poultry is easy to tear apart, or whether there's any fresh blood on meat or poultry, or whether the fish is transparent and easy to cut off by knife and fork.
- ★ Concentration of Vapor
 - It's a normal phenomenon that vapor concentrates during microwave cooking when the water inside food is vaporized. Generally speaking, food with coverings concentrates less vapor than that without coverings. Therefore, good ventilation shall be kept inside the oven.

- ★ Frying Pan for Microwave Purpose
 - Before using frying pan or other utensils, segregate the pan from ceramic bottom with a heat-resistant ware such as ceramic plate, in order to avoid crack of ceramic bottom due to overheating. The frying pan shall not work too long time in the oven.
- ★ Preservative Paper for Microwave Purpose
 - When cooking grease food, make sure that the preservative paper is not in contact with food since the paper is very likely to melt.
- ★ Plastic Cookware for Microwave Purpose
 - Some plastic cookware for microwave purpose can not be used to cook food containing too much oil or sugar.
- ★ Plastic Cookware for Microwave Purpose
 - Some plastic cookware for microwave purpose can not be used to cook food containing too much oil or sugar.

● **Method of Defrosting Foods**

- ★ Steak
 - Wrap the slim end of the steaks with aluminum foil.
 - Lay the steakes on a pan with the thinnest part in the middle. Make sure that the steaks are chopped apart entirely.
 - Turn over the steaks when they are half done, and wrap up the defrosted part with aluminum foil.
 - Put the steaks back on pan, and close oven door to resume defrosting.
 - When defrosting is done, keep the steaks in aluminum foil for 5-15 minutes.
- ★ Beef (Chopped Meat)
 - Wrap the edge of beef with aluminum foil, and put it on a pan.
 - Turn over the beef when they are half done. Take out the defrosted part, and wrap the beef again.
 - Close oven door to resume defrosting.
 - When defrosting is done, keep the beef in aluminum foil for 5-15 minutes.
- ★ Roasted Meat (Beef/Pork/Lamb)
 - Wrap the edge of meat ith aluminum foil.
 - Put it on a pan.
 - Turn over the meat when it's half done, and wrap the defrosted part.
 - Close oven door to resume defrosting.
 - When defrosting is done, keep the meat in aluminum foil for 10-30 minutes.
- ★ Poultry
 - Remove commercial packing of the poultry, and wrap the wings and feet with aluminum foil.
 - Put it on a pan with its chest downward.
 - Turn over the poultry when it's half done, and wrap the defrosted part.
 - Close oven door to resume defrosting.
 - When defrosting is done, keep the poultry in aluminum foil for 10-30 minutes.
- ★ Chicken Chips (Wings and Legs)
 - Wrap the bare bones with aluminum foil.
 - Put the chips on a pan.
 - Turn over the chips when it's half done, and wrap the defrosted part.
 - Close oven door to resume defrosting.
 - When defrosting is done, keep the chips in aluminum foil for 5-30 minutes.

Normal Phenomena and Trouble Shooting

● **Precautions**



Be careful of microwave radiation. There's microwave radiation and high voltage inside the oven. In order to reduce the risk of hazard to human being, do not disassemble this appliance by yourself except for qualified service people and never expose yourself in the radiation from microwave generator or transmitter.

1. If the oven door or seal is damaged, do not use the oven anymore until it's fixed by qualified service people.
2. If the socket and fuse are not in good condition, please contact FOTILE's after-sales service center or qualified service people.
3. Except for qualified service people, do not allow anyone to make any inspection on the oven, including disassembling the cover.

● **Normal Phenomena**

1. Radio and TV reception may be interfered when microwave oven operating. It's similar to the interference of small electrical appliances, like mixer, vacuum cleaner, and electric fan. It's normal.
2. Although the microwave oven will not be damaged when operating empty loaded for a short time, the user should try best to avoid this from happening.
3. The microwave oven must be cleaned regularly, especially when microwave or grill functions are applied, because the oil stain accumulating at the top of cavity and walls may cause smoke.
4. The temperature inside cavity will rise if the magnetron operates for a long time. In order to protect the magnetron, the oven will shut off automatically and resume operation shortly afterwards. It's normal.

● **Trouble Shooting**

Trouble	Possible Cause	Solution
No display on LED	Power cord not plugged in tightly.	Unplug, then plug again after 10 seconds.
	Fuse blowing or circuit breaker works.	Contact FOTILE authorized service people.
	Trouble with socket.	Test socket with other appliances.
	In standby mode.	Press any button to end standby.
Microwave oven can not be started.	Door not closed well.	Close door well.
	Pressing "Start/OK" button not pressed yet.	Press "Start" button.
	Other programs are chosen.	Press Pause / Cancele" button to cancel chosen program and choose a new program.
	Mistake in choosing programs	Choose correct program based on the manual.
	Mistake in pressing " Pause / Cancele" button.	Choose correct cooking program.